

READ THIS FIRST



Model G0613/G0614
*****IMPORTANT UPDATE*****

For Machines Mfd. Since 02/24
and Owner's Manual Revised 04/18

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

The following changes were recently made since the owner's manual was printed:

- Coolant pump has changed.
- Blade tension gauge has been added.

Aside from this information, all other content in the owner's manual applies and **MUST** be read and understood for your own safety. **IMPORTANT: Keep this update with the owner's manual for future reference.**

For questions or help, contact our Tech Support at (570) 546-9663 or techsupport@grizzly.com.

New Coolant Pump



G0613 Pump Shown

Old Coolant Pump



G0613 Pump Shown

COPYRIGHT © APRIL, 2024 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
#CS23153 PRINTED IN TAIWAN

Revised G0613 Specifications

Product Dimensions:

Approximate Net Weight..... 477 lbs.

Motors:

Pump 110V (As Shipped)

Type..... Sealed/Waterproof
Horsepower..... 1/8 HP
Voltage..... 110V
Phase..... Single-Phase
Amps..... 0.34A
Speed..... 3000 RPM
Cycle..... 50/60 Hz
Bearings..... Shielded & Permanently Lubricated

Pump 220V (Included in 220V Conversion Kit)

Type..... Sealed/Waterproof
Horsepower..... 1/8 HP
Voltage..... 220V
Phase..... Single-Phase
Amps..... 0.23A
Speed..... 3000 RPM
Cycle..... 50/60 Hz
Bearings..... Shielded & Permanently Lubricated

Revised G0614 Specifications

Product Dimensions:

Approximate Net Weight..... 585 lbs.

Motors:

Pump

Phase..... Single-Phase
Amps..... 0.23A
Speed..... 3000 RPM
Cycle..... 50/60 Hz



Revised G0613 Coolant Pump Wiring





Figure 1. G0613 pump motor wiring (110V).



Revised G0614 Coolant Pump Wiring






Figure 2. G0614 pump motor wiring.




Revised G0613 Parts



REF	PART #	DESCRIPTION
4V2	P0613004V2	ANCHOR BLOCK V2.02.24
12	P0613012	CONCAVE WASHER
15V2	P0613015V2	FIXED BLOCK V2.02.24
136V3	P0613136V3	PUMP 110V 1PH V3.02.24
136V3-1	P0613136V3-1	COOLANT HOSE 8MM ID
136V3-2	P0613136V3-2	FLOW VALVE
136V3-3	P0613136V3-3	PUMP JUNCTION BOX
136V3-4	P0613136V3-4	R CAPACITOR 1M 350V
136V3-5	P0613136V3-5	PIPE ELBOW MALE 3/8" X 8MM
136V3X	P0613136V3X	PUMP 220V 1PH V3.02.24

REF	PART #	DESCRIPTION
136V3X-1	P0613136V3X-1	COOLANT HOSE 8MM ID
136V3X-2	P0613136V3X-2	FLOW VALVE
136V3X-3	P0613136V3X-3	PUMP JUNCTION BOX
136V3X-4	P0613136V3X-4	R CAPACITOR 1M 350V
136V3X-5	P0613136V3X-5	PIPE ELBOW MALE 3/8" X 8MM
149	P0613149	THRUST BEARING 51203
150	P0613150	BLADE TENSION GAUGE
257A	P0613257A	ON/OFF & EMGNCY SW 220V
263A	P0613263A	CIRCUIT BREAKER 7A 220V 1P
264V2	P0613264V2	220V CONVERSION KIT V2.02.24

Revised G0614 Parts



REF	PART #	DESCRIPTION
4V2	P0614004V2	ANCHOR BLOCK V2.02.24
12	P0614012	CONCAVE WASHER
15V2	P0614015V2	FIXED BLOCK V2.02.24
136V3	P0614136V3	PUMP 220V 1PH V3.02.24
136V3-1	P0614136V3-1	COOLANT HOSE 8MM ID
136V3-2	P0614136V3-2	FLOW VALVE


REF	PART #	DESCRIPTION
136V3-3	P0614136V3-3	PUMP JUNCTION BOX
136V3-4	P0614136V3-4	R CAPACITOR 1M 350V
136V3-5	P0614136V3-5	PIPE ELBOW MALE 3/8" X 8MM
149	P0614149	THRUST BEARING 51203
150	P0614150	BLADE TENSION GAUGE



SECTION 2: CIRCUIT REQUIREMENTS

Availability

Before installing the machine, consider the availability and proximity of the required power supply circuit. If an existing circuit does not meet the requirements for this machine, a new circuit must be installed. To minimize the risk of electrocution, fire, or equipment damage, installation work and electrical wiring must be done by an electrician or qualified service personnel in accordance with all applicable codes and standards.



Full-Load Current Rating

The full-load current rating is the amperage a machine draws at 100% of the rated output power. On machines with multiple motors, this is the amperage drawn by the largest motor or sum of all motors and electrical devices that might operate at one time during normal operations.

G0613 Full-Load Current Rating (110V) .. 15.74A

G0613 Full-Load Current Rating (220V).... 7.93A

G0614 Full-Load Current Rating (220V)....5.23A

The full-load current is not the maximum amount of amps that the machine will draw. If the machine is overloaded, it will draw additional amps beyond the full-load rating.

If the machine is overloaded for a sufficient length of time, damage, overheating, or fire may result—especially if connected to an undersized circuit. To reduce the risk of these hazards, avoid overloading the machine during operation and make sure it is connected to a power supply circuit that meets the specified circuit requirements.

Circuit Information

A power supply circuit includes all electrical equipment between the breaker box or fuse panel in the building and the machine. The power supply circuit used for this machine must be sized to safely handle the full-load current drawn from the machine for an extended period of time. (If this machine is connected to a circuit protected by fuses, use a time delay fuse marked D.)



Note: *Circuit requirements in this manual apply to a dedicated circuit—where only one machine will be running on the circuit at a time. If machine will be connected to a shared circuit where multiple machines may be running at the same time, consult an electrician or qualified service personnel to ensure circuit is properly sized for safe operation.*

Grounding Requirements

This machine **MUST** be grounded. In the event of certain malfunctions or breakdowns, grounding reduces the risk of electric shock by providing a path of least resistance for electric current.


Improper connection of the equipment-grounding wire can result in a risk of electric shock. The wire with green insulation (with or without yellow stripes) is the equipment-grounding wire. If repair or replacement of the power cord or plug is necessary, do not connect the equipment-grounding wire to a live (current carrying) terminal.

Check with a qualified electrician or service personnel if you do not understand these grounding requirements, or if you are in doubt about whether the tool is properly grounded. If you ever notice that a cord or plug is damaged or worn, disconnect it from power, and immediately replace it with a new one.



⚠️ WARNING

Serious injury could occur if you connect machine to power before completing setup process. **DO NOT** connect to power until instructed later in this manual.



⚠️ CAUTION

No adapter should be used with plug. If plug does not fit available receptacle, or if machine must be reconnected for use on a different type of circuit, reconnection must be performed by an electrician or qualified service personnel, and it must comply with all local codes and ordinances.

G0613 Circuit Requirements for 110V

The Model G0613 is prewired to operate on a power supply circuit that has a verified ground and meets the following requirements:

Nominal Voltage 110V, 115V, 120V
Cycle 60 Hz
Phase Single-Phase
Power Supply Circuit 20 Amps
Plug/Receptacle NEMA 5-20

This machine is equipped with a power cord that has an equipment-grounding wire and a grounding plug. Only insert plug into a matching receptacle (outlet) that is properly installed and grounded in accordance with all local codes and ordinances. **DO NOT** modify the provided plug!




Figure 3. Typical 5-20 plug and receptacle.

G0613 Circuit Requirements for 220V

The Model G0613 can be converted to operate on a power supply circuit that has a verified ground and meets the requirements listed below. (Refer to **Voltage Conversion** instructions for details.)

Nominal Voltage 208V, 220V, 230V 240V
Cycle 60 Hz
Phase Single-Phase
Power Supply Circuit 15 Amps
Plug/Receptacle NEMA 6-15




Figure 4. Typical 6-15 plug and receptacle.

G0614 Circuit Requirements for 220V

The Model G0614 is prewired to operate on a power supply circuit that has a verified ground and meets the following requirements:

Nominal Voltage 208V, 220V, 230V 240V
Cycle 60 Hz
Phase 3-Phase
Power Supply Circuit 20 Amps
Plug/Receptacle NEMA 15-20 or L15-20




Figure 5. Typical 15-20 plug and receptacle.



Extension Cords

We do not recommend using an extension cord with this machine. If you must use an extension cord, only use it if absolutely necessary and only on a temporary basis.

Extension cords cause voltage drop, which can damage electrical components and shorten motor life. Voltage drop increases as the extension cord size gets longer and the gauge size gets smaller (higher gauge numbers indicate smaller sizes).

Any extension cord used with this machine must be in good condition and contain a ground wire and matching plug/receptacle. Additionally, it must meet the following size requirements:

G0613 Minimum Gauge Size (110V)....12 AWG
G0613 Minimum Gauge Size (220V) ...18 AWG
G0614 Minimum Gauge Size (220V) ...18 AWG
Maximum Length (Shorter is Better).....50 ft.

Model G0613 Voltage Conversion

The Model G0613 can be converted to 220V operation. This conversion consists of: 1) Disconnecting the machine from power, 2) replacing the 110V components with the 220V components included in the P0613264V2 conversion kit, 3) replacing the plug, and 4) rewiring the main motor for 220V operation.

All the wiring changes must be inspected by a qualified electrician or service personnel before the machine is connected to the power source. If, at any time during this procedure you need assistance, call Grizzly Tech Support at (570) 546-9663.

Items Needed	Qty
220V Conversion Kit (#P0613264V2)	1
Wire Cutters/Stripper.....	1
Phillips Head Screwdriver #2	1
Wrench or Socket 7mm.....	1
Open-End Wrench 14mm.....	1
Electrical Tape	As Needed
Wire Nut (18#AWG)	1
NEMA 6-15 Plug.....	1

To convert Model G0613 to 220V operation:

1. DISCONNECT MACHINE FROM POWER!
2. Cut off existing 5-20 plug.
3. Replace the existing ON/OFF switch and circuit breaker with those included in the 220V conversion kit, wiring them according to the **G0613 Control Box Diagram** shown in the G0613/G0614 manual update for machines manufactured since 07/06.
4. Rewire the main motor according to the **G0613 220V Component Wiring** shown in the G0613/G0614 manual update for machines manufactured since 07/06.
5. Replace the existing coolant pump with the one included in the 220V conversion kit, wiring it according to the 220V diagram in **Revised G0613 Coolant Pump Wiring** shown on **Page 3** of this update.
6. Install 6-15 plug on power cord, according to plug manufacturer's instructions.
 - If plug manufacturer's instructions are not available, NEMA standard 6-15 plug wiring is shown in **Figure 6**.




Figure 6. NEMA standard 6-15 plug wiring.



8. When the blade is around both wheels, adjust the position so the back of the blade is against the shoulder of the wheels.
9. Reinstall the blade cover and the blade guide guards.
10. Now go to the **Blade Tension** procedure and set the blade tension.

Blade Tension

The Model G0613/G0614 features a blade tension gauge to assist you with blade tensioning. Proper blade tension is essential to avoid blade vibration, twist, or slippage on the wheels. A correctly tensioned blade provides long blade life, straight cuts, and efficient cutting.

The three major signs of incorrect blade tension are: 1) The blade stalls in the cut and slips on the wheels, 2) the blade frequently breaks, and 3) the bandsaw does not make straight cuts.

NOTICE

Loosen blade tension at the end of each day to prolong blade life.

To tension the blade:

1. DISCONNECT MACHINE FROM POWER!
2. Slide the upper blade guide as far as possible towards the blade tension assembly.

3. Adjust the blade tension handwheel (see **Figure 37**) until the indicator on the blade tension gauge indicates the desired tension. Turn the handwheel clockwise to tighten the blade or counterclockwise to loosen the blade.

— **For G0613:** Blades should be adjusted to about 24,000 PSI.

— **For G0614:** Blades should be adjusted to about 30,000 PSI.




Figure 37. Location of the blade tension handwheel and gauge.

4. Adjust the blade guides as close to the workpiece as possible to minimize side-to-side blade movement before proceeding with operation.



READ THIS FIRST



Model G0614

*****IMPORTANT UPDATE*****

For Machines Mfd. Since 06/20
and Owner's Manual Revised 04/18

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com


The following changes were recently made since the owner's manual was printed:

- Saw body frame and output shaft key changed.

Aside from this information, all other content in the owner's manual applies and **MUST** be read and understood for your own safety. **IMPORTANT: Keep this update with the owner's manual for future reference.**

For questions or help, contact our Tech Support at (570) 546-9663 or techsupport@grizzly.com.

Revised Parts



REF	PART #	DESCRIPTION
7V4	P0614007V4	BODY FRAME V4.06.20

REF	PART #	DESCRIPTION
27V2	P0614027V2	KEY 8 X 7 X 30 RE V2.06.20

COPYRIGHT © OCTOBER, 2022 BY GRIZZLY INDUSTRIAL, INC.
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**
#CS22517 PRINTED IN TAIWAN

READ THIS FIRST



Model G0613/G0614
*****IMPORTANT UPDATE*****
 For Machines Mfd. Since 07/06
 and Owner's Manual Revised 12/07

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com


The following changes were recently made to this machine since the owner's manual was printed:

- **G0613:** Changed pump rotary switch, wiring diagram, and component diagram.
- **G0614:** Changed parts, wiring diagram, and components diagram.

Aside from this information, all other content in the owner's manual applies and **MUST** be read and understood for your own safety. **IMPORTANT: Keep this update with the owner's manual for future reference.**

For questions or help, contact our Tech Support at (570) 546-9663 or techsupport@grizzly.com.


G0613 Parts



REF	PART #	DESCRIPTION
255V2	P0613255V2	PUMP ROTARY SWITCH XB7ND21 V2.07.16



Figure 1. G0613 control panel.



REF	PART #	DESCRIPTION
136V2	P0613136V2	PUMP 110V 1PH V2.07.07
136-1V2	P0613136-1V2	COOLANT HOSE 8MM ID V2.05.11
136-2V2	P0613136-2V2	FLOW VALVE V2.07.07
136-3V2	P0613136-3V2	PUMP JUNCTION BOX V2.07.07
136V2-4	P0613136V2-4	R CAPACITOR FJ SHGSX-V 3MFD 400V




Figure 2. G0613 pump motor capacitor.

COPYRIGHT © JULY, 2017 BY GRIZZLY INDUSTRIAL, INC. REVISED MARCH, 2022 (BL)
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
 #JH18697 PRINTED IN TAIWAN




G0614 Control Box Parts



REF	PART #	DESCRIPTION
246V2	P0614246V2	FUSE HOUSING GIKO KA FSB102-1-2 V2.07.06
247V2	P0614247V2	FUSE 7 X 30MM 1A V2.07.06
250V3	P0614250V3	CONTACTOR CAI D404A V3.03.15
251V3	P0614251V3	CONTACTOR CO9D10G7 V3.03.15
252V3	P0614252V3	CONTACTOR CO9D10G7 V3.03.15
252V3-1	P0614252V3-1	OL RELAY NTH 4.5-6A V3.03.15

REF	PART #	DESCRIPTION
253V2	P0614253V2	ON BUTTON AP-PBF-22-1/0G V2.07.06
254V2	P0614254V2	SPEED SWITCH AP-ASS-223-2AW V2.07.06
255V2	P0614255V2	ROTARY SWITCH AP-ASS-222-1AW V2.07.06
256V2	P0614256V2	OFF BUTTON AP-PBF-22-1-BR V2.07.06
257V2	P0614257V2	E-STOP BUTTON AP ALEPBC-22-1BR V2.07.06

G0614 Headstock & Pump Motor Parts



REF	PART #	DESCRIPTION
7V3	P0614007V3	BODY FRAME V3.02.16
39V3	P0614039V3	KNOB BOLT M8-1.25 X 25 6-LOBE V3.02.16
40V3	P0614040V3	FIXED BLOCK V3.02.16

REF	PART #	DESCRIPTION
44V2	P0614044V2	HANDLE PIPE V2.02.16
81	P0614081	CAP SCREW M8-1.25 X 25
82	P0614082	SET SCREW M8-1.25 X 8



Inventory

The following is a list of items shipped with your machine. Before beginning setup, lay these items out and inventory them.

If any non-proprietary parts are missing (e.g. a nut or a washer), we will gladly replace them; or for the sake of expediency, replacements can be obtained at your local hardware store.

G0613 Inventory

Shipping Crate: (Figure 3)	Qty
A. Splash Tray.....	1
B. Vise Clamp Handle	1
C. Blade Tension Handles	2
D. Work Stop Arm.....	1
E. Work Stop Rod.....	1
F. Headstock Handle.....	1
G. Hardware	1
—Carriage Screws $\frac{5}{16}$ "-18 X $\frac{5}{8}$ ".....	8
—Hex Nuts $\frac{5}{16}$ "-18	8
—Flat Washers 10mm	4
—Hex Bolts M10-1.5 X 25	4
H. Front/Rear Panels	2
I. Left/Right Panels.....	2




Figure 3. G0613 inventory.

G0614 Inventory

Shipping Crate: (Figure 4)	Qty
A. Splash tray	1
B. Vise Clamp Handle	1
C. Blade Tension Handles	2
D. Work Stop Arm.....	1
E. Work Stop Rod.....	1
F. Front/Rear Panels	2
G. Left/Right Panels.....	2
H. Hardware.....	1
—Carriage Screws $\frac{5}{16}$ "-18 X $\frac{5}{8}$ ".....	8
—Hex Nuts $\frac{5}{16}$ "-18	8
—Flat Washers 10mm	4
—Hex Bolt M10-1.5 X 25	4





Figure 4. G0614 inventory.

NOTICE

If you cannot find an item on this list, carefully check around/inside the machine and packaging materials. Often, these items get lost in packaging materials while unpacking or they are pre-installed at the factory.



G0613 Control Box Diagram



G0613 Control Box




Figure 5. G0613 control box wiring.



Figure 6. G0613 control panel.



G0613 110V Component Wiring





Figure 7. Pump motor wiring.





Figure 8. Main motor wiring.





Figure 9. Limit switch wiring.



G0613 220V Component Wiring





Figure 10. Pump motor wiring.




Figure 11. Main motor wiring.





Figure 12. Limit switch wiring.



G0614 Control Box




Figure 13. G0614 control box wiring.



Figure 14. G0614 control panel.



G0614 Component Wiring





Figure 15. Motor wiring.




Figure 16. Pump motor wiring.





Figure 17. Limit switch wiring.





Model G0613/G0614

IMPORTANT UPDATE


Applies to Models Mfg. Since 5/11
and Owner's Manual Revised 1/10

We made the following changes to the Model G0613/G0614 Swivel Mast Metal Cutting Bandsaw:


- Changed the blade coolant nozzles.
- Changed the size of the upper blade guide lock.
- Changed the G0614 body frame to accommodate the guide lock.
- Changed the G0614 blade guides.
- Changed the base and stand to a welded one-piece assembly.

The new blade coolant nozzles can be removed from the blade guides and used to wash down the cutting area. Aside from the new nozzles, the above changes do not affect how the machine assembles or functions. Only the parts listed on the following pages have changed. Use the original owner's manual when referring to all other parts.

Aside from the information contained in this update, all other content in the owner's manual applies to this machine. For your own safety, you **MUST** read and understand this update and the G0613/G0614 Owner's Manual. *If you have any further questions about this manual update or the changes made to the machine, contact our Technical Support at (570) 546-9663 or email techsupport@grizzly.com.*




G0613 New Headstock and Bow Parts



REF	PART #	DESCRIPTION	REF	PART #	DESCRIPTION
39V2	P0613039V2	LOCK KNOB BOLT M10-1.5 X 15 V2.06.08	53-2V2	P0613053-2V2	COOLANT HOSE 6MM ID V2.05.11
40V2	P0613040V2	BLADE GUIDE LOCK PLATE V2.06.08	53-3V2	P0613053-3V2	STEEL T-CONNECTOR V2.05.11
53-1V2	P0613053-1V2	FLOW VALVE 6MM V2.05.11			


G0613 New Stand Parts (G0613)



REF	PART #	DESCRIPTION	REF	PART #	DESCRIPTION
136-1V2	P0613136-1V2	COOLANT HOSE 8MM ID V2.05.11	136-2	P0613136-2	FLOW VALVE



G0614 New Headstock and Bow Parts




REF	PART #	DESCRIPTION
7V2	P0614007V2	BODY FRAME V2.06.08
39V2	PCAP90M	CAP SCREW M10-1.5 X 55 V2.06.08
40V2	P0614040V2	BLADE GUIDE LOCK PLATE V2.06.08
53V2	P0614053V2	ADJUSTMENT BLOCK FRONT V2.05.11
53-1V2	P0614053-1V2	FLOW VALVE 6MM V2.05.11
53-2V2	P0614053-2V2	COOLANT HOSE 6MM ID V2.05.11

REF	PART #	DESCRIPTION
53-3V2	P0613053-3V2	STEEL T-CONNECTOR V2.05.11
65V2	P0614065V2	ADJUSTMENT BLOCK REAR V2.05.11
84	P0614084	BLADE GUIDE BRACKET
85	P0614085	BLADE GUIDE
86	PCAP23M	CAP SCREW M4-.7 X 12

Only the parts listed in this update have changed. Use the original owner's manual when referring to all other parts.




G0614 New Stand Parts



REF	PART #	DESCRIPTION
136-1V2	P0613136-1V2	COOLANT HOSE 8MM ID V2.05.11


REF	PART #	DESCRIPTION
136-2	P0613136-2	FLOW VALVE

G0613 Electrical Box Stand



REF	PART #	DESCRIPTION
238V2	P0613238V2	CONTROL BOX STAND V2.06.08
234	PW01M	FLAT WASHER 8MM
243	PCAP31M	CAP SCREW M8-1.25 X 25

G0614 Electrical Box Stand



REF	PART #	DESCRIPTION
238V2	P0614238V2	CONTROL BOX STAND V2.06.08
234	PW01M	FLAT WASHER 8MM
243	PCAP31M	CAP SCREW M8-1.25 X 25

Only the parts listed in this update have changed. Use the original owner's manual when referring to all other parts.



Grizzly *Industrial, Inc.*®

Model G0613/G0614 Swivel Mast Metal Cutting Bandsaw OWNER'S MANUAL



COPYRIGHT © NOVEMBER, 2006 BY GRIZZLY INDUSTRIAL, INC. REVISED APRIL, 2018 (HE)

**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

#CR8638 PRINTED IN TAIWAN



WARNING!

This manual provides critical safety instructions on the proper setup, operation, maintenance, and service of this machine/tool. Save this document, refer to it often, and use it to instruct other operators.

Failure to read, understand and follow the instructions in this manual may result in fire or serious personal injury—including amputation, electrocution, or death.

The owner of this machine/tool is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, cutting/sanding/grinding tool integrity, and the usage of personal protective equipment.

The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.



WARNING!

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- **Lead from lead-based paints.**
- **Crystalline silica from bricks, cement and other masonry products.**
- **Arsenic and chromium from chemically-treated lumber.**

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

Table of Contents

INTRODUCTION	2	SECTION 5: ACCESSORIES	27
Manual Accuracy	2	SECTION 6: MAINTENANCE	29
Contact Info.....	2	Schedule	29
Machine Data Sheet	3	Cleaning.....	29
Machine Data Sheet	5	Lubrication	29
Identification	7	SECTION 7: SERVICE	30
Control Panel	8	Troubleshooting	30
SECTION 1: SAFETY	9	Blade Change	32
Safety Instructions for Machinery	9	Blade Tension.....	33
Additional Safety for Bandsaws	11	Blade Guides (G0613).....	34
SECTION 2: CIRCUIT REQUIREMENTS	12	Blade Guides (G0614).....	36
110/220V 1-Phase (G0613).....	12	Swivel Stops	38
220V 3-Phase (G0614).....	13	Feed Stop	39
SECTION 3: Setup	14	Feed Auto Stop.....	39
Items Needed for Setup.....	14	Blade-to-Vise Squareness	40
Unpacking	14	Electrical Components (G0613).....	41
Inventory	15	Electrical Components (G0614).....	42
Clean Up	16	G0613 Wiring Diagram	46
Site Considerations.....	16	G0614 Wiring Diagram	47
Cabinet Assembly	17	SECTION 8: PARTS	48
Mounting to Shop Floor	17	Headstock and Bow Breakdown (G0613) ...	48
Cutting Fluid System.....	18	Headstock and Bow Breakdown (G0614) ...	50
Recommended Adjustments.....	19	Base Breakdown (G0613)	52
Test Run	19	Base Breakdown (G0614)	54
SECTION 4: OPERATIONS	20	Electrical Box Breakdown (G0613).....	56
Cutting Angle	20	Electrical Box Breakdown (G0614).....	57
Workstop.....	21	Cabinet & Gearbox (G0613 & G0614).....	59
Vise	21	Labels and Placement	61
Blade Selection	23	WARRANTY AND RETURNS	65
Blade Speed	23		
Splash Tray.....	24		
Using Blade Guides	24		
Setting Feed Rate	25		
Cutting Fluid Tips	26		
Operation Tips	26		


INTRODUCTION

Manual Accuracy

We are proud to offer this manual with your new machine! We've made every effort to be exact with the instructions, specifications, drawings, and photographs of the machine we used when writing this manual. However, sometimes errors do happen and we apologize for them.

Also, owing to our policy of continuous improvement, **your machine may not exactly match the manual**. If you find this to be the case, and the difference between the manual and machine leaves you in doubt, check our website for the latest manual update or call technical support for help.

Before calling, find the manufacture date of your machine by looking at the date stamped into the machine ID label (see below). This will help us determine if the manual version you received matches the manufacture date of your machine.



For your convenience, we post all available manuals and manual updates for free on our website at www.grizzly.com. Any updates to your model of machine will be reflected in these documents as soon as they are complete.

Contact Info

We stand behind our machines. If you have any service questions, parts requests or general questions about the machine, please call or write us at the location listed below.

Grizzly Industrial, Inc.
1203 Lycoming Mall Circle
Muncy, PA 17756
Phone: (570) 546-9663
Fax: (800) 438-5901
E-Mail: techsupport@grizzly.com

If you have any comments regarding this manual, please write to us at the address below:

Grizzly Industrial, Inc.
c/o Technical Documentation Manager
P.O. Box 2069
Bellingham, WA 98227-2069
Email: manuals@grizzly.com





MACHINE DATA SHEET

Customer Service #: (570) 546-9663 • To Order Call: (800) 523-4777 • Fax #: (800) 438-5901

MODEL G0613 SWIVEL MAST METAL-CUTTING BANDSAW

Product Dimensions:

Floor to Table Height 35⁵/₈"
 Overall Dimensions 63"L x 29³/₄"W x 66"H
 Approximate Net Weight 418 lbs.

Shipping Dimensions:

Overall Dimensions (Crate 1, Machine) 26¹/₂"L x 50¹/₂"W x 34⁹/₁₆"H
 Crate Dimensions (Crate 2, Cabinet) 25¹³/₁₆"L x 6³/₈"W x 24¹³/₁₆"H
 Type Wood Slat Crate
 Approximate Shipping Weight (Crate 1, Machine) 451 lbs.
 Approximate Shipping Weight (Crate 2, Cabinet) 59.5 lbs.

Electrical:

Controls Centralized Control Panel Operation
 Switch Pushbutton
 Switch Voltage 110V/220V
 Recommended Cord Gauge Three-Wire, 14 AWG
 Recommended Breaker Size 20 A

Motors:

Main

Type TEFC Capacitor Start Induction
 Horsepower 1 HP
 Voltage (Prewired 110V) 110V/220V
 Phase Single
 Amps 15.4A/7.7A
 Speed 3450 RPM
 Cycle 60 Hz
 Number of Speeds 1
 Blade Drive Sealed Worm Gear
 Bearings Shielded and Lubricated

Pump

Type Sealed/Waterproof
 Horsepower 1/8 HP
 Voltage (Prewired 110V) 110V/220V
 Phase Single
 Amps 0.9A/0.45A
 Speed 3450 RPM
 Cycle 60 Hz
 Bearings Shielded and Lubricated



Main Specifications:

Operation Info

Blade Speeds.....	314 FPM
Blade Size.....	3/4" x 82"
Head Swivel	0° to 60°

Cutting capacities:

0°, round	7"
0°, rectangular.....	5" x 8 1/4"
+45°, round	4 1/4"
+45°, rectangular.....	4" x 4 1/4"
+60°, round	2"
+60°, rectangular.....	2 3/4" x 2"
Miter cutting capacity	0° to 60°

Other Specifications:

Country of Origin.....	Taiwan
Warranty.....	1 Year
Serial Number Location	Grizzly ID Label

Features:

- Swivel Base with Degree Scale
- Centralized Control Panel
- Heavy-duty All Steel, One Piece Base
- Adjustable Hydraulic Down Feed
- Extra Clamping Capacity Vise with Lever Lock
- Quick Release Vise
- Tooth Selection Chart
- Built-in Cutting fluid System
- Automatic Shut Off
- Adjustable Blade Guide System Blade Wheels Have Heavy-duty Ball Bearings





MACHINE DATA SHEET

Customer Service #: (570) 546-9663 • To Order Call: (800) 523-4777 • Fax #: (800) 438-5901

MODEL G0614 SWIVEL MAST METAL-CUTTING BANDSAW

Product Dimensions:

Floor to table height 35⁵/₈"
 Overall dimensions 68"L x 26⁷/₈"W x 69"H
 Approximate Net Weight 506 lbs.

Shipping Dimensions:

Overall Dimensions (Crate 1, Machine) 28¹/₈"L x 53"W x 52"H
 Crate Dimensions (Crate 2, Cabinet) 34¹/₂"L x 6³/₈"W x 24¹/₂"H
 Type Wood Slat Crate
 Approximate Shipping Weight (Crate 1, Machine) 550 lbs.
 Approximate Shipping Weight (Crate 2, Cabinet) 72.7 lbs.

Electrical:

Controls Centralized Control Panel Operation
 Switch Pushbutton
 Switch Voltage 220V, 3-Phase
 Recommended Cord Gauge 4-Wire, 14 AWG
 Recommended Breaker Size 15A

Motors:

Main

Type TEFC
 Horsepower 1¹/₂ HP
 Voltage 220V
 Phase 3-Phase
 Amps 3.6/5A
 Speed 1725, 3450 RPM
 Cycle 60 Hz
 Number of Speeds 2
 Blade Drive Sealed Worm Gear
 Bearings Shielded and Lubricated

Pump

Type Sealed/Waterproof
 Horsepower 1/8 HP
 Voltage 220V
 Phase 3-Phase
 Amps 0.65
 Speed 3450 RPM
 Cycle 60 Hz
 Bearings Shielded and Lubricated



Main Specifications:

Operation Info

Blade Speeds.....170, 341 FPM
Blade Size..... 1" x 97⁵/₈"
Head Swivel 0° to 60°

Cutting capacities:

0°, round 8³/₄"
0°, rectangular..... 6" x 9¹/₂"
+45°, round 5"
+45°, rectangular..... 5" x 5"
+60°, round 2³/₄"
+60°, rectangular..... 2³/₄" x 2³/₄"
Miter cutting capacity 0° to 60°

Other Specifications:

Country of Origin.....Taiwan
Warranty.....1 Year
Serial Number LocationGrizzly ID Label

Features:

- Swivel Base with Degree Scale
- Two-Speed Motor
- Centralized Control Panel
- Heavy-duty All Steel, One Piece Base
- Adjustable Hydraulic Down Feed
- Extra Clamping Capacity Vise with Lever Lock
- Quick Release Vise
- Tooth Selection Chart
- Built-in Cutting fluid System
- Automatic Shut Off
- Adjustable Blade Guide System Blade Wheels Have Heavy-duty Ball Bearings and Carbide Rub Blocks



Identification




Figure 1. G0613/14 Machine Identification.

- | | |
|-------------------------------------|---|
| A. Blade Tension Handwheel | J. Main Support Cabinet |
| B. Cutting Fluid Flow Valves | K. Headstock Swivel Lock Lever |
| C. Control Panel | L. Swivel Degree Scale |
| D. Main Electrical Box | M. Work Stop |
| E. Bandsaw Motor | N. Vise Lock Lever |
| F. Worm Drive Gearbox | O. Vise Clamp Handwheel |
| G. Feed Rate Control Knob | P. Blade Guide Position Lock Lever |
| H. Feed ON/OFF Valve | Q. Headstock Lift Arm and Handle |
| I. Cutting Fluid Pump | |



Control Panel




Figure 2. G0613 control panel.

A. ON/OFF Push Button Switch: When the cover is open, it allows access to the normal-operation ON/OFF pushbutton switch that is used to start and stop the bandsaw.

B. EMERGENCY Stop and Anti-Start Lockout Cover: When the cover is closed but not latched shut, it serves as an easy-to-find EMERGENCY STOP button with anti-start lockout. If pushed in an emergency situation, the cover pushes the OFF button and then latches shut, preventing accidental machine startup.

Note: Both bandsaws also have an automatic shut-off (limit switch) that turns the saw **OFF** at the completion of the cutting arc.

C. Circuit Breaker: Kills power in the event of high current draw or motor overload.

D. Cutting Fluid Pump Switch: Turns the cutting fluid pump **ON**.




Figure 3. G0614 control panel.

E. ON Button: Turns the motor **ON** and starts the bandsaw.

F. OFF Button: Turns the motor **OFF** and stops the bandsaw.

G. Cutting Speed Switch: Changes the motor speed between 1725 and 3450 RPM, giving two cutting speeds of 170 and 341 FPM.

H. Cutting Fluid Pump Switch: Turns the cutting fluid pump **ON**.

I. EMERGENCY STOP/OFF Button: Kills power to the system and turns the motor **OFF**. Twist the button until it pops out to re-energize the system.



SECTION 1: SAFETY


WARNING

For Your Own Safety, Read Instruction Manual Before Operating this Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words which are intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures.

 **DANGER** Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.

 **WARNING** Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

 **CAUTION** Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE This symbol is used to alert the user to useful information about proper operation of the machine.

WARNING

Safety Instructions for Machinery

- 1. READ THROUGH THE ENTIRE MANUAL BEFORE STARTING MACHINERY.** Machinery presents serious injury hazards to untrained users.
- 2. ALWAYS USE ANSI APPROVED SAFETY GLASSES WHEN OPERATING MACHINERY.** Everyday eyeglasses only have impact resistant lenses, they are NOT safety glasses.
- 3. ALWAYS WEAR AN NIOSH APPROVED RESPIRATOR WHEN OPERATING MACHINERY THAT PRODUCES DUST.** Wood dust is a carcinogen and can cause cancer and severe respiratory illnesses.
- 4. ALWAYS USE HEARING PROTECTION WHEN OPERATING MACHINERY.** Machinery noise can cause permanent hearing damage.
- 5. WEAR PROPER APPAREL. DO NOT** wear loose clothing, gloves, neckties, rings, or jewelry which may get caught in moving parts. Wear protective hair covering to contain long hair and wear non-slip footwear.
- 6. NEVER OPERATE MACHINERY WHEN TIRED, OR UNDER THE INFLUENCE OF DRUGS OR ALCOHOL.** Be mentally alert at all times when running machinery.



WARNING

Safety Instructions for Machinery

7. **ONLY ALLOW TRAINED AND PROPERLY SUPERVISED PERSONNEL TO OPERATE MACHINERY.** Make sure operation instructions are safe and clearly understood.
8. **KEEP CHILDREN AND VISITORS AWAY.** Keep all children and visitors a safe distance from the work area.
9. **MAKE WORKSHOP CHILD PROOF.** Use padlocks, master switches, and remove start switch keys.
10. **NEVER LEAVE WHEN MACHINE IS RUNNING.** Turn power **OFF** and allow all moving parts to come to a complete stop before leaving machine unattended.
11. **DO NOT USE IN DANGEROUS ENVIRONMENTS.** DO NOT use machinery in damp, wet locations, or where any flammable or noxious fumes may exist.
12. **KEEP WORK AREA CLEAN AND WELL LIT.** Clutter and dark shadows may cause accidents.
13. **USE A GROUNDED EXTENSION CORD RATED FOR THE MACHINE AMPERAGE.** Undersized cords overheat and lose power. Replace extension cords if they become damaged. DO NOT use extension cords for 220V machinery.
14. **ALWAYS DISCONNECT FROM POWER SOURCE BEFORE SERVICING MACHINERY.** Make sure switch is in OFF position before reconnecting.
15. **MAINTAIN MACHINERY WITH CARE.** Keep blades sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
16. **MAKE SURE GUARDS ARE IN PLACE AND WORK CORRECTLY BEFORE USING MACHINERY.**
17. **REMOVE ADJUSTING KEYS AND WRENCHES.** Make a habit of checking for keys and adjusting wrenches before turning machinery **ON**.
18. **CHECK FOR DAMAGED PARTS BEFORE USING MACHINERY.** Check for binding and alignment of parts, broken parts, part mounting, loose bolts, and any other conditions that may affect machine operation. Repair or replace damaged parts.
19. **USE RECOMMENDED ACCESSORIES.** Refer to the instruction manual for recommended accessories. The use of improper accessories may cause risk of injury.
20. **DO NOT FORCE MACHINERY.** Work at the speed for which the machine or accessory was designed.
21. **SECURE WORKPIECE.** Use clamps or a vise to hold the workpiece when practical. A secured workpiece protects your hands and frees both hands to operate the machine.
22. **DO NOT OVERREACH.** Keep proper footing and balance at all times.
23. **MANY MACHINES WILL EJECT THE WORKPIECE TOWARD THE OPERATOR.** Know and avoid conditions that cause the workpiece to "kickback."
24. **ALWAYS LOCK MOBILE BASES (IF USED) BEFORE OPERATING MACHINERY.**
25. **BE AWARE THAT CERTAIN DUST MAY BE HAZARDOUS** to the respiratory systems of people and animals, especially fine dust. Make sure you know the hazards associated with the type of dust you will be exposed to and always wear a respirator approved for that type of dust.



WARNING

Additional Safety for Bandsaws

- 1. BLADE CONDITION.** Do not operate with dull, cracked or badly worn blade. Inspect blades for cracks and missing teeth before each use.
- 2. HAND PLACEMENT.** Never position fingers or thumbs in line with the cut. Hands could be crushed in vise or by falling machine components or cut by the blade.
- 3. ENTANGLEMENT HAZARDS.** Do not operate this bandsaw without blade guard in place. Otherwise, loose clothing, jewelry, long hair and work gloves can be drawn into working parts.
- 4. BLADE REPLACEMENT.** When replacing blades, make sure teeth face toward the workpiece. Wear gloves to protect hands and safety glasses to protect eyes.
- 5. WORKPIECE HANDLING.** Always support the workpiece with table, vise, or other support fixture. Flag long pieces to avoid a tripping hazard. Never hold the workpiece with your hands during a cut.
- 6. LOSS OF STABILITY.** Unsupported workpieces may jeopardize machine stability and cause the machine to tip and fall, which could cause serious injury.
- 7. POWER INTERRUPTION.** Unplug machine after power interruption. Machines without magnetic switches can start up after power is restored.
- 8. FIRE HAZARD.** Use EXTREME CAUTION if cutting magnesium. Using the wrong cutting fluid will lead to chip fire and possible explosion.
- 9. CUTTING FLUID SAFETY.** Always follow manufacturer's cutting fluid safety instructions. Pay particular attention to contact, contamination, inhalation, storage and disposal warnings. Spilled cutting fluid is a slipping hazard and a toxicity hazard.
- 10. ATTENTION TO WORK AREA.** Never leave a machine running and unattended. Pay attention to the actions of others in the area to avoid unintended accidents.
- 11. MAINTENANCE/SERVICE.** All inspections, adjustments, and maintenance are to be done with the machine **OFF** and the power disconnected to the machine. Wait for all moving parts to come to a complete stop.
- 12. HEARING PROTECTION & HAZARDS.** Noise generated by blade and workpiece vibration, material handling, and power transmission can cause permanent hearing loss over time and interfere with communication and audible signals. Always wear hearing protection.
- 13. HOT SURFACES.** Due to friction, the workpiece, chips, and some machine components can be hot enough to burn you.

WARNING

No list of safety guidelines can be complete. Every shop environment is different. Like all machines there is danger associated with the Model G0613/14. Accidents are frequently caused by lack of familiarity or failure to pay attention. Use this machine with respect and caution to lessen the possibility of operator injury. If normal safety precautions are overlooked or ignored, serious personal injury may occur.



SECTION 2: CIRCUIT REQUIREMENTS

110/220V 1-Phase (G0613)

!WARNING

The Model G0613 is prewired for 110V operation. If you plan to use your machine at 220V, you must rewire the motor and install the conversion kit part number P0613264. Refer to the wiring diagram and consult a qualified electrician.

Amperage Draw

The Model G0613 features a 110/220V motor that is prewired for 110V and draws the following amps under maximum load:

Motor Draw at 220V.....7.7 Amps
 Motor Draw at 110V 15.4 Amps

Circuit Requirements

The power supply circuit for your machine **MUST** be grounded and rated for the amperage given below. Never replace a circuit breaker on an existing circuit with one of higher amperage without consulting a qualified electrician to ensure compliance with wiring codes. **If you are unsure about the wiring codes in your area or you plan to connect your machine to a shared circuit, consult a qualified electrician.**

110V Circuit.....20 Amps
 220V Circuit..... 15 Amps

220V Connection

Rewire the motors according to the wiring connection diagram on the inside cover of the motor and pump junction boxes. Refer to **G0613 Single Phase 220V Wiring Diagram** on **Page 46** for general wiring details. Also use the following 220V plug for your machine on a dedicated circuit (see **Figure 4**):

220V Plug & Receptacle6-15





Figure 4. Recommended 220V 6-15 outlet and plug.

Extension Cords

Using extension cords may reduce the life of the motor. Instead, place the machine near a power source. If you must use an extension cord:

- For 110V, use at least a 12 gauge cord that does not exceed 50 feet in length.
- For 220V, use at least a 14 gauge cord that does not exceed 50 feet in length.
- Ensure that the extension cord contains a ground wire and plug pin.



220V 3-Phase (G0614)

! WARNING

Serious personal injury could occur if you connect your machine to the power source before you have completed the setup process. **DO NOT** connect the machine to the power source until instructed to do so.

Amperage Draw

The Model G0614 features a 1.5 HP, 220V, 3-phase motor that draws the following amps under maximum load:

Motor Draw at 220V..... 5 Amps

Circuit Requirements

The power supply circuit for your machine **MUST** be grounded and rated for the amperage given below. Never replace a circuit breaker on an existing circuit with one of higher amperage without consulting a qualified electrician to ensure compliance with wiring codes. **If you are unsure about the wiring codes in your area or you plan to connect your machine to a shared circuit, consult a qualified electrician.**

220V 3-Phase Circuit 15 Amps





Figure 5. NEMA L15-20R Plug and receptacle.

Grounding

In the event of an electrical short, grounding reduces the risk of electric shock. The grounding wire in the power cord must be properly connected to the grounding prong on the plug; likewise, the outlet must be properly installed and grounded. All electrical connections must be made in accordance with local codes and ordinances.



Extension Cords


We do not recommend using an extension cord for the machine power supply. Instead, locate your machine where you can eliminate the need of an extension cord.

If you find it absolutely necessary to use an extension cord, make sure the extension cord contains a ground wire, and a grounding lug.

Use at least a 10 gauge cord that does not exceed 50 feet in length!




SECTION 3: Setup




!WARNING

This machine presents serious injury hazards to untrained users. Read through this entire manual to become familiar with the controls and operations before starting the machine!




!WARNING

Wear safety glasses during the entire setup process!



!WARNING

The Model G0613/14 is an extremely heavy machine. Serious personal injury may occur if safe moving methods are not followed. To be safe, you will need assistance and power equipment when moving the shipping crate and removing the machine from the crate.



!CAUTION

CUTTING HAZARD!
Blades are sharp! Put on heavy leather gloves when handling a blade or making adjustments near a blade or cutter!

Items Needed for Setup

The following items are needed to complete the setup process, but are not included with your machine:

Description	Qty
• Safety Glasses (for each person)	1
• Solvent Cleaner.....	As Needed
• Shop Towels.....	As Needed
• Mounting Hardware (optional)....	As Needed
• Forklift or Hoist	1
• Cutting Fluid	1 Gallon
• Assistant.....	1

Unpacking

The Model G0613/14 was carefully packed when it left our warehouse. If you discover the machine is damaged after you have signed for delivery, *please immediately call Customer Service at (570) 546-9663 for advise.*

Save the containers and all packing materials for possible inspection by the carrier or its agent. *Otherwise, filing a freight claim can be difficult.*

When you are completely satisfied with the condition of your shipment, you should inventory the contents.



Inventory

After all the parts have been removed from the crate, you should have the following accessories:

Shipping Crate: (Figure 6)	Qty
A. Splash tray (only for G0614).....	1
B. Handle	1
C. Work Stop Arm	1
D. Work Stop Lock Lever	1
E. Work Stop Rod	1
F. Hardware	1
—Carriage Screw 5/16-18 X16	8
—Hex Nut 5/16-18	8
—Flat Washer 10mm	4
—Hex Bolt M10-1.5 X 25	4




Figure 6. G0613/14 inventory.

In the event that any nonproprietary parts are missing (e.g. a nut or a washer), we would be glad to replace them, or for the sake of expediency, replacements can be obtained at your local hardware store.


NOTICE

Some hardware/fasteners on the inventory list may arrive pre-installed on the machine. Check these locations before assuming that any items from the inventory list are missing.




Clean Up

The unpainted surfaces are coated with a waxy oil to prevent corrosion during shipment. Remove this protective coating with a solvent cleaner or degreaser, such as shown in **Figure 7**. For thorough cleaning, some parts must be removed. **For optimum performance, clean all moving parts or sliding contact surfaces.** Avoid chlorine-based solvents, such as acetone or brake parts cleaner that may damage painted surfaces. Always follow the manufacturer's instructions when using any type of cleaning product.



! WARNING
Gasoline and petroleum products have low flash points and can explode or cause fire if used to clean machinery. **DO NOT** use these products to clean the machinery.



! CAUTION
Many cleaning solvents are toxic if inhaled. Minimize your risk by only using these products in a well ventilated area.

G2544—Solvent Cleaner & Degreaser
H9692—Orange Power Degreaser
Great products for removing shipping grease.



Figure 7. Cleaner/degreasers available from Grizzly.

Site Considerations

Floor Load and Working Clearances

Refer to the **Machine Data Sheet** for the weight and footprint specifications of your machine. Some floors may require additional reinforcement to support both the machine and operator.

Consider existing and anticipated needs, size of material to be processed through each machine, and space for auxiliary stands, work tables or other machinery. See **Figure 8** for the minimum working clearances.




Figure 8. Minimum working clearances.



Cabinet Assembly

To assemble the cabinet:

1. Assemble the four cabinet sides together with the eight M8-1.25 x 16 hex bolts and nuts.
2. Using a hoist and straps that can hold at least 600 lbs. (see **Figure 9**), lower the bandsaw and base onto the top of the cabinet so the swivel lock lever protrudes through the side of the cabinet and the four cabinet mounting holes line up.
3. Secure the bandsaw base to the cabinet with the four M10-1.5 x 35 hex bolts and the flat washers.





Figure 9. G0613/14 lifting points.

!WARNING



The Model G0613/14 is an extremely heavy machine. Serious personal injury may occur if safe moving methods are not followed. To be safe, you will need assistance and power equipment when moving the shipping crate and removing the machine from the crate.

Mounting to Shop Floor

Typical Machine Mounting Options

Although not required, we recommend that you mount your new machine to the floor. Using machine mounts, shown in **Figure 10**, gives the advantage of fast leveling and vibration reduction. Lag shield anchors with lag bolts and anchor studs are two popular methods for anchoring an object to a concrete floor. Because this is an optional step and floor materials may vary, floor mounting hardware is not included. Generally, you can either bolt your machine to the floor or mount it on machine mounts. It may be necessary to level your machine after mounting.

NOTICE

Anchor studs are stronger and more permanent alternatives to lag shield anchors; however, they will stick out of the floor, which may cause a tripping hazard if you decide to move your machine.



Figure 10. Typical options for machine mounting.



Cutting Fluid System

	<p>⚠ WARNING FIRE HAZARD! DO NOT cut magnesium when using oil-water solutions as a cutting fluid! Always use a cutting fluid intended for magnesium. The water in the solution will cause a magnesium-chip fire.</p>
---	--

This bandsaw has a built-in cutting fluid system that extends the life of your bandsaw blades by lowering the temperature of the blade and workpiece.

See **Cutting Fluid** on **Page 26** for additional information.

To use the cutting fluid system:

1. Remove the Phillip head screw and the reservoir screen.
2. Thoroughly clean and remove any foreign material that may have fallen inside the reservoir during shipping and machine use.
3. Fill the reservoir (**Figure 11**) with your chosen cutting fluid solution and replace the screen.




Figure 11. Cutting fluid system reservoir and cover.

4. Turn the cutting fluid pump switch **ON**, and adjust the valves on the cutting fluid hoses to control the flow of cutting fluid (see **Figure 12**).

Note: Too much flow at the fluid nozzle will make a mess and can make the work area unsafe; and not enough fluid at the cut will heat the blade, causing the blade teeth to load up and break.




Figure 12. Cutting fluid control valve.

NOTICE

Keep the screen clear so cutting fluid can recycle to the pump reservoir. NEVER operate the pump with the reservoir below the low mark or you will over-heat the pump and void your warranty!

5. Monitor the cutting fluid level frequently to keep the system working properly.



Recommended Adjustments


The adjustments listed below have been performed at the factory. However, because of the many variables involved with shipping, we recommend that you verify the following adjustments before the **Test Run** and to ensure cutting results meet your standards.

Step-by-step instructions on verifying these adjustments can be found in **SECTION 7: SERVICE ADJUSTMENTS**.

Factory adjustments that should be verified:

1. Blade Tension (**Page 33**).
2. G0613 Blade Guide Adjustment (**Page 34**).
3. G0614 Blade Guide Adjustment (**Page 36**).
4. Stop Adjustments (**Page 38**).
5. Blade Squaring Adjustment (**Page 40**).

Test Run



Starting the machine:

1. Read the entire instruction manual.
2. Make sure all tools and foreign objects have been removed from the machine.
3. Make sure that you verify the **Recommended Adjustments** listed on this page.
4. Fill the cutting fluid reservoir with cutting fluid if not done so already, DO NOT run the pump without cutting fluid or you will damage the pump.
5. Put on safety glasses and secure loose clothing or long hair.
6. Connect the bandsaw to power.
7. Raise the bandsaw and close the feed rate control knob to keep the saw in place.
8. Start the bandsaw while keeping your finger near the EMERGENCY STOP/OFF button at all times during the test run. The bandsaw should run smoothly with little or no vibration.

Note: *If the EMERGENCY STOP/OFF button is pressed, it needs to be twisted until it pops out or the bandsaw will not start.*

—If you hear or see any problems, immediately stop the bandsaw and correct before continuing.


—If you need any help with your bandsaw call our Tech Support at (570) 546-9663.



SECTION 4: OPERATIONS


!WARNING

Damage to your eyes, lungs, and ears could result from using this machine without proper protective gear. Always wear safety glasses, a respirator, and hearing protection when operating this machine.



!WARNING

Loose hair and clothing could get caught in machinery and cause serious personal injury. Keep loose clothing and long hair away from moving machinery.



NOTICE

This bandsaw is for trained operators only. **WE STRONGLY RECOMMEND** that you read books, trade magazines, and get formal training before beginning any projects. Regardless of the content in this section, Grizzly Industrial will not be held liable for accidents caused by lack of training.

Cutting Angle

Your bandsaw has a locking turret with a range of 0° to 60° degrees.

To set the angle of cut:

1. Raise the bow to the highest position and lock in place (**Figure 13**).




Figure 13. Feed ON/OFF Valve.

2. Move the swivel lock lever (**Figure 14**), to the left and rotate the headstock until the scale indicates the angle that you need.




Figure 14. Swivel lock lever.

3. Move the swivel lock lever to the right to lock the headstock in place. The cutting angle is now set.



Workstop

Your bandsaw has an adjustable workstop (**Figure 15**) that is easy to install and to use.

To install the workstop:

1. Thread the workstop rod in the base and tighten the jam nut.
2. Slide the workstop onto the rod.




Figure 15. Workstop assembly.

3. Measure the distance from the blade to the workstop, slide workstop to the needed position and tighten the lock lever.

Vise

The vise has a quick tighten/release lever and, depending on the cut angle or workpiece shape, you can remove or install the aluminium vise clamp plate (**Figure 17**) for additional holding force.

To use the vise:

1. Raise the bow and lock it in place by closing the feed ON/OFF valve (**Figure 16**).




Figure 16. Feed ON/OFF Valve.

2. Insert the workpiece between the jaws.
3. Use the handwheel (**Figure 17**) to move the jaws so they are within 1/8" from clamping the workpiece.




Figure 17. Vise options and controls.

4. Use the vise lock lever to hold the workpiece and quickly release the jaws to move the workpiece after a cut.



5. Use the chart shown in **Figure 18** as a guide to quickly position the workpiece between the vise jaws correctly and to avoid slipping during a cut. **DO NOT CUT STEEL THAT IS STACKED OR BUNDLED.** One or more workpieces will slip and damage the saw blade.

⚠ CAUTION
Always turn the saw OFF and allow the blade to come to a complete stop before using the vise! Failure to follow this caution may lead to injury.




Figure 18. Vise clamping options.



Blade Selection

The Model G0613 uses a 3/4" wide x 82" long x 0.35" thick bandsaw blade.

The Model G0614 uses a 1" wide x 97 5/8" long x 0.35" thick bandsaw blade.

Do some research for your specific situation so you get the best blade to match your needs.

Selecting the right blade for the job depends on a variety of factors, such as the type of material being cut, hardness of the material, material shape, machine capability, and operator technique.

Grizzly offers a variety of selections that can be found in the current catalog and in **SECTION 5: ACCESSORIES** on **Page 27**.

The chart shown in **Figure 19** is a reproduction of the chart on the blade cover of your bandsaw. Use it as a rough guideline.

Blade Speed

The Model G0613 is a single speed (314 FPM) bandsaw. Like the G0614, it has a cutting fluid system which gives the saw a wider cutting range than a single speed bandsaw that is not equipped with a cutting fluid system.

The Model G0614 has a two speed control ranging from 170 to 341 feet per minute (FPM). The speed is controlled by a rotary switch and can be switched while the motor is operating.

NOTICE

On the Model G0614, DO NOT change motor speed during a cut as this may overload a series of engaged blade teeth.




Figure 19. G0613/14 general blade selection and speed chart.



The table shown in **Figure 20** is a sampling of speed rates for various materials. Use these as a guideline, and use the cutting fluid system on your bandsaw to get the most life from your blades.

Material	Alloy ASTM Number	Blade Speed
Copper Alloys	173,932	Hi
	330,365	Hi
	623,624	Hi
	230,260,272	Lo
	280,264,632,655	Lo
	101,102,110,122,172	Lo
	1751,182,220,510	Lo
	625, 706, 715, 934	Lo
	630	Lo
	811	Lo
Carbon Steels	1117	Hi
	1137	Hi
	1141,1144	Hi
	1141 High Stress	Hi
	1030	Hi
	1008,1015,1020,1025	Hi
	1035	Hi
	1018,1021,1022	Hi
	1026,1513	Hi
	A36 (SHAPES),1040	Hi
	1042,1541	Lo
	1044,1045	Lo
	1060	Lo
1095	Lo	
Nickle	8615, 8620, 8622	Hi
Chrome	4340, E4340, 8630	Lo
Molybdenum	8640	Lo
Alloys	E9310	Lo
Tool Steels	A-6	Lo
	A-2	Lo
	A-10	Lo
	D-2	Lo
	H-11,H-12,H-13	Lo
Stainless Steels	420	Lo
	430	Lo
	410,502	Lo
	414	Lo
	431	Lo
	440C	Lo
	304, 324	Lo
	304L	Lo
	347	Lo
	316, 316L	Lo
	416	Lo

Figure 20. Material speed table.

Splash Tray

Use the splash tray to reduce cutting fluid lost at the end of a workpiece when cutting at 60°. The splash tray fits over the lip of the base as illustrated in **Figure 21**.



Figure 21. Splash tray installation.

Using Blade Guides

The upper blade guide should be as close to the workpiece as possible. This helps ensure straight cuts by keeping the blade from twisting or drifting off the cut line.

To adjust the upper blade guide:

Loosen the lever shown in **Figure 22** and slide the upper blade guide as close to the workpiece as possible, then tighten the knob.




Figure 22. Blade guide lock lever.



Setting Feed Rate

Feed rate is the speed at which the bow and the saw blade cuts through a workpiece. The feed rate dial adjusts the feed rate. If a lubricant is used while cutting, the feed rate can be increased by approximately 15%. The feed ON/OFF lever starts and stops the lowering of the bow.

To set the feed rate:

1. Raise the bow to the highest position and lock it in place with the feed ON/OFF lever.
2. Set the feed rate dial to the desired feed rate; 1 is the slowest and 9 is the fastest.





Figure 23. Feed rate dial.

3. Start the pump and the bandsaw and begin cutting.
 - If you get evenly-shaped chips that are slightly curled or spiraled with only a slight color change; the feed rate, blade speed, cutting fluid type, and blade type are correct.
 - If you get a tightly curled, warm shavings, brown to black in color, reduce the feed rate, increase blade speed or both.
 - If you get smoking blue-colored metal chips, slow the blade speed, use cutting fluid, reduce the feed rate, or a combination of the three.
 - If you get thin powder-like silver colored chips, increase feed rate, decrease the blade speed, or both.



Cutting Fluid Tips



While simple in concept and function, many issues must be taken into account to find and use the correct cutting fluid. For example, you must consider the workpiece type and hardness, its shape, the blade feed rate, blade TPI, the tooth type, and blade type, and cutting speed. Always follow all product warnings and contact the fluid manufacturer for unanswered questions.

Use the selections below to choose the appropriate cutting fluids:

- For cutting low alloy, low carbon, and general-purpose category metals with a bi-metal blade—use a water soluble cutting fluid.
- For cutting stainless steels, high carbon, and high alloy metals, brass, copper and mild steels—use "Neat Cutting Oil" (commonly undiluted mineral oils) that have extreme pressure additives (EP additives).
- For cutting cast iron, cutting fluid is not recommended.

Remember: Too much flow at the cutting fluid nozzle will make a mess and can make the work area unsafe; and not enough fluid at the cut will heat the blade, causing the blade teeth to load up and break.

Operation Tips

The following tips will help you safely and effectively operate your bandsaw and get the maximum life out of your saw blades.



Tips for horizontal cutting:

- Use the work stop to quickly and accurately cut multiple pieces of stock to the same length.
- Clamp the material firmly in the vise jaws to ensure a straight cut through the material and use the positive lock to speed production.
- Let the blade reach full speed before engaging the workpiece.
- Never start a cut with the blade in contact with the workpiece and do not start a cut on a sharp edge.
- Chips should be curled and silvery. If the chips are thin and powder like, increase your feed rate.
- Burned chips indicate a need to reduce your blade speed.
- Wait until the blade has completely stopped before removing the workpiece from the vise, and avoid touching the cut end—it could be very hot!
- Support long pieces so they won't fall when cut, and flag the ends to alert passers-by of potential danger.
- Adjust the blade guides as close as possible to the workpiece to minimize side-to-side blade movement.
- Use cutting fluid when possible to increase blade life.



SECTION 5: ACCESSORIES

MODEL G0613

82" x 3/4" x 0.032"
Variable Pitch
Bi-Metal Blades:

H9726— 4-6 VP
H9727— 5-8 VP
H9728— 6-10 VP
H9729— 8-12 VP
H9730— 10-14 VP

MODEL G0614

97-5/8" x 1" x 0.032"
Variable Pitch
Bi-Metal Blades:

H9731— 4-6 VP
H9732— 5-8 VP
H9733— 6-10 VP
H9734— 8-12 VP
H9735— 10-14 VP




Figure 24. Blades

H5408—Blade Tensioning Gauge

The Blade Tensioning Gauge ensures long blade life, reduced blade breakage, and straight cutting by indicating correct tension. A precision dial indicator provides you with a direct readout in PSI.



Figure 25. H5408 Blade Tensioning Gauge.

H5405—Lenox® Lube Tube™

Lenox® Lube Tube™ is a stick lubricant designed to prevent heat buildup. Apply it directly to the blade to improve overall blade life and productivity. Can be used on ferrous and non-ferrous metals. Biodegradable, non-toxic, and non-staining 14.5 oz tube.



Figure 26. Lenox® Lube Tube™.

H9240—Rustlick Cutting Oil

Rustlick WS5050 Heavy-Duty Soluble Cutting Oil. General purpose and heavy duty applications. Can be used on all metals except titanium.



Figure 27. H9240 Rustlick Cutting Oil.

Call 1-800-523-4777 To Order



G5618—Deburring Tool with Two Blades

G5619—Extra Aluminum Blades

G5620—Extra Brass and Cast Iron Blade

The quickest tool for smoothing freshly machined metal edges. Comes with two blades—one for steel/aluminum and one for brass/cast iron.



Figure 28. G5618 Deburring tool.

T20502—Face Shield Crown Protector 7"

T20503—Face Shield Window

T20448—Economy Clear Safety Glasses

T20452—"Kirova" Anti-Reflective Glasses

T20456—"Dakura" Clear Safety Glasses

These glasses meet ANSI Z87.1-2003 specifications. Buy extras for visitors or employees. You can't be too careful with shop safety!



Figure 29. Our most popular eye protection.

H4978—Deluxe Earmuffs - 27dB

H4979—Twin Cup Hearing Protector - 29dB

T20446—Earplugs - 200 Pair

Protect yourself comfortably with a pair of cushioned earmuffs or earplugs. Especially important if you or employees operate for hours at a time.



Figure 30. Our most popular ear protection.

G9256—6" Dial Caliper

G9257—8" Dial Caliper

G9258—12" Dial Caliper

These traditional dial calipers are accurate to 0.001" and can measure outside surfaces, inside surfaces, and heights/depths. Features stainless steel, shock resistant construction and a dust proof display.





Figure 31. Grizzly® Dial Calipers.

Call 1-800-523-4777 To Order



SECTION 6: MAINTENANCE



! WARNING
Always disconnect power to the machine before performing maintenance. Failure to do this may result in serious personal injury.

Schedule

For optimum performance from your machine, follow this maintenance schedule and refer to any specific instructions given in this section.

Daily Check:

- Loose mounting bolts.
- Damaged saw blade.
- Worn or damaged wires.
- Any other unsafe condition.
- Clean and wipe down after each use.
- Proper blade tension.
- Check cutting fluid level.

Monthly Check:

- Lubricate vise screw.
- Check cutting fluid level.

Annual Check:

- Replace cutting fluid and clean out tank. If the saw is used heavily, clean the tank and replace the cutting fluid at a sooner intervals.

Cleaning

Cleaning the Model G0613/14 is relatively easy. After using your bandsaw, vacuum up excess chips or by sweeping them up.

If using water based cutting fluid, wipe down and lubricate areas where the liquid may collect, causing rust after a period of time.

Lubrication

1. Before applying lubricant to any area, wipe the area clean to avoid contamination. Lubricate the blade tensioner leadscrew (**Figure 32**) with general purpose grease, and apply a coat of general purpose oil to all unprotected cast iron surfaces.

Note: All bearings and the gearbox on the Model G0613/14 are lubricated and sealed for life. No further attention is needed unless damage occurs.



Figure 32. Lubrication points.

2. Lubricate the leadscrew as needed with general purpose grease. Apply a thin layer all along the leadscrew surface (see **Figure 33**).





Figure 33. Vise leadscrew lubrication area.



SECTION 7: SERVICE

Review the troubleshooting and procedures in this section to fix your machine if a problem develops. If you need replacement parts or you are unsure of your repair skills, then feel free to call our Technical Support at (570) 546-9663.

Troubleshooting




Motor & Electrical

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
Machine does not start or a breaker trips.	<ol style="list-style-type: none"> 1. E-Stop button pressed. 2. Plug/receptacle is at fault or wired incorrectly. 3. Start capacitor is at fault (G0613). 4. Wall fuse/circuit breaker is blown/tripped. 5. Motor connection wired incorrectly. 6. Power supply is at fault/switched OFF. 7. Motor ON/OFF switch is at fault. 8. Wiring is open/has high resistance. 9. Motor is at fault. 	<ol style="list-style-type: none"> 1. Twist E-Stop button until it pops out. 2. Test for good contacts; correct the wiring. 3. Test/replace capacitor if faulty. 4. Ensure correct size for machine load; replace weak breaker. 5. Correct motor wiring connections. 6. Ensure hot lines have correct voltage on all legs and main power supply is switched ON. 7. Replace faulty ON/OFF switch. 8. Check for broken wires or disconnected/corroded connections, and repair/replace as necessary. 9. Test/repair/replace.
Machine stalls or is under-powered.	<ol style="list-style-type: none"> 1. Wrong blade for the workpiece material. 2. Wrong workpiece material. 3. Feed rate/cutting speed too fast for task. 4. Blade is slipping on wheels. 5. Incorrect power supply voltage. 6. Motor bearings are at fault. 7. Plug/receptacle is at fault. 8. Motor connection is wired incorrectly. 9. Motor has overheated. 10. Motor is at fault. 	<ol style="list-style-type: none"> 1. Use blade with correct properties for your type of cutting. 2. Use metal with correct properties for your type of cutting. 3. Decrease feed rate/cutting speed. 4. Adjust blade guides and tension. 5. Ensure hot lines have correct voltage on all legs. 6. Test by rotating shaft; rotational grinding/loose shaft requires bearing replacement. 7. Test for good contacts; correct the wiring. 8. Correct motor wiring connections. 9. Clean off motor, let cool, and reduce workload. 10. Test/repair/replace.
Machine has vibration or noisy operation.	<ol style="list-style-type: none"> 1. Motor fan is rubbing on fan cover. 2. Blade is at fault. 3. Wormgear is at fault. 4. Wrong blade for material. 5. Speed is set too slow. 	<ol style="list-style-type: none"> 1. Replace dented fan cover; replace loose/damaged fan. 2. Replace/resharpen blade. 3. Rebuild gearbox for bad gear(s)/bearing(s). 4. Change blade. 5. Adjust speed as required.



Bandsaw Operations




SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
Machine is loud when cutting or bogs down in the cut.	<ol style="list-style-type: none"> 1. Excessive feed rate. 2. The blade TPI is too great, or the material is too coarse. 	<ol style="list-style-type: none"> 1. Refer to Feed Rate on Page 25, or Blade Speed on Page 23 and adjust as required. 2. Refer to Blade Selection on Page 23 and adjust as required.
Blades break often.	<ol style="list-style-type: none"> 1. Blade is not tensioned correctly. 2. The workpiece is loose in the vise. 3. The feed or cut speed is wrong. 4. The blade TPI is too great, or the material is too coarse. 5. The blade is rubbing on the wheel flange. 6. The bandsaw is being started with the blade resting on the workpiece. 7. The guide bearings are misaligned, or the blade is rubbing on the wheel flange. 8. The blade is too thick, or the blades are of low quality. 	<ol style="list-style-type: none"> 1. Check to see that blade is not excessively tight or too loose. 2. Clamp the workpiece tighter, or use a jig to hold the workpiece. 3. Refer to Feed Rate on Page 25, or Blade Speed on Page 23, and adjust as required. 4. Refer to Blade Selection on Page 23, and adjust as required. 5. Refer to Blade Squaring on Page 40, and adjust as required. 6. Start bandsaw and then slowly lower the headstock by setting the feed rate. 7. Refer to Blade Squaring on Page 40, or Blade Guides on Page 34, and adjust as required. 8. Use a higher quality blade.
Blade dulls prematurely.	<ol style="list-style-type: none"> 1. The cutting speed is too fast. 2. The blade TPI is too coarse. 3. The blade feed pressure is too light. 4. The workpiece has hard spots, welds, or scale. 5. The blade is twisted. 6. The blade is slipping on the wheels. 	<ol style="list-style-type: none"> 1. Refer to Blade Speed on Page 23, and adjust as required. 2. Refer to Blade Selection on Page 23, and adjust as required. 3. Refer to Feed Rate on Page 25, and adjust as required. 4. Increase the feed pressure, and reduce the cutting speed. 5. Replace the blade. 6. Refer to Blade Tension on Page 33, and adjust as required.
Blade wears on one side.	<ol style="list-style-type: none"> 1. The blade guides are worn. 2. The blade guide slide bracket is loose. 3. The wheels are out of alignment. 	<ol style="list-style-type: none"> 1. Refer to Blade Guides on Page 34 and replace or adjust. 2. Tighten the blade guide bracket. 3. Refer to Blade Squaring on Page 40, and adjust as required.
Teeth are ripping from the blade.	<ol style="list-style-type: none"> 1. The feed pressure is too heavy and the blade speed is too slow; or the blade TPI is too coarse for the workpiece. 2. The workpiece is vibrating in the vise. 3. The blade gullets are loading up with chips. 	<ol style="list-style-type: none"> 1. Refer to Blade Selection on Page 23 and decrease the feed pressure. Refer to Feed Rate on Page 25, and adjust as required. 2. Re-clamp the workpiece in the vise, and use a jig if required. 3. Use a coarser-tooth blade.
The cuts are crooked.	<ol style="list-style-type: none"> 1. The feed pressure is too high. 2. The guide bearings are out of adjustment, or too far away from the workpiece. 3. The blade tension is low. 4. The blade is dull. 5. The blade speed is wrong. 	<ol style="list-style-type: none"> 1. Refer to Feed Rate on Page 25, and adjust as required. 2. Refer to Blade Guides on Page 34 and replace or adjust. 3. Refer to Blade Tension on Page 33, and adjust as required. 4. Refer to Blade Change on Page 32 and replace the blade. 5. Refer to Blade Speed on Page 23, and adjust as required.



Blade Change

Change the blade when it becomes dull, damaged, or when you are using materials that require a blade of a certain type or tooth count.



To change the blade on the bandsaw:

1. DISCONNECT THE BANDSAW FROM POWER!
2. Raise the bow of the bandsaw for access and close the feed control lever to hold the bow in place.




Figure 34. Blade tension handwheel and tensioner, and bow lift handle.

3. Slide the blade guides as far apart as possible, and remove the wheel access cover.
4. Remove both of the blade guide guards (**Figures 35 and 36**) from the bandsaw.





Figure 35. Installed blade and guide guard.

5. Loosen the blade tension handle in **Figure 34** and slip the blade off of the wheels.
6. Install the new blade through both blade guide bearings and around the bottom wheel.

 **Tip:** This is a good time to adjust the blade guides if you have not done so recently.





Figure 36. Installed blade and guide guard.

7. Hold the blade around the bottom wheel with one hand and slip it around the top wheel with the other hand, keeping the blade between the blade guide bearings.

 **Tip:** You can use a block of wood to tap on the blade in order to fully seat the blade.

Note: Do not flip the blade inside out so the blade will be installed in the wrong direction. Make sure the blade teeth are facing toward the workpiece and the direction of cut.



8. When the blade is around both wheels, adjust the position so the back of the blade is against the shoulder of the wheels.
9. Reinstall the blade cover and the blade guide guards.
10. Now go to the **Blade Tension** procedure and set the blade tension.

2. Using the graduated scale on the blade tension indicator (**Figure 38**) turn the blade tension handwheel so the tension is in the orange range when using the saw. When the saw is not being used, adjust the tension to the yellow range.

Note: For carbon blades, the blade tension should be 20,000 PSI. For bi-metal blades, like the one supplied with your machine, the blade should be tensioned from 20,000 to 22,000 PSI.

Blade Tension

Proper blade tension is essential to long blade life, straight cuts, and efficient cutting. The Model G0613/14 features a blade tension indicator to assist you with blade tensioning.

Two major signs that you do not have proper blade tension are: 1) The blade stalls in the cut and slips on the wheels, and 2) the blade frequently breaks from being too tight.

NOTICE

Loosen blade tension at the end of each day to prolong blade life.

To tension the blade on the bandsaw:

1. Locate the blade tension handle (**Figure 37**) and add a few drops of oil on the lead screw.




Figure 37. Blade tension handwheel, tensioner, bow lift handle.

If you are using a blade tensioning gauge, like the one found in **SECTION 5: ACCESSORIES** on **Page 27**, you will find the specifications below useful. Follow the manual instructions included with your gauge and the blade manufacturer's recommendations on blade tension.




Figure 38. Blade tension scale.

3. When the correct tension is reached, adjust the tension stop bolt so when you need to de-tension and re-tension the blade, the handwheel will stop at your predetermined tension setting. (**Figure 39**).





Figure 39. Blade tension stop bolt.



Blade Guides (G0613)

The blade guides have a basic factory adjustment, but due to shipping and storage we recommend that you readjust the blade guides yourself to ensure the cuts will be your standards.



CAUTION
CUTTING HAZARD!
Blades are sharp! Put on heavy leather gloves when handling a blade or making adjustments near a blade or cutter!

To adjust the blade guides:

1. Make sure the blade is oiled, tensioned, and tracking correctly.
2. DISCONNECT THE BANDSAW FROM POWER!
3. Raise and lock the bow in place and slide the guides together as close as you can and lock into place.
4. Loosen the two cap screws and the blade guide guard shown in **Figure 40**.




Figure 40. Upper blade guide components.

5. Loosen the cap screws (**Figure 42**), and adjust the blade guide housing so the back of the blade slightly touches the bearing and the guide housing is not tilted.

6. Tighten the cap screws.

Note: To access the cap screws on the other blade guide, you will have to remove the two Phillips head screws (**Figure 41**) and move the limit switch and its bracket out of the way.




Figure 41. Lower blade guide limit switch.

7. Loosen the 14mm jam nuts and rotate the 7mm hex on top of the bearing eccentrics (**Figure 42**), and adjust the bearings against the side of the blade.

Tip: There should be no gap between the blade and the bearings. To set this clearance to zero without fighting the twist of the blade, remove the blade guide assemblies, set this clearance to the blade thickness, then reinstall the blade guide assemblies.




Figure 42. Blade guide adjustment locations.



8. Double check bearing adjustments.
9. Adjust the other blade guide, and reinstall the blade guide guards and the limit switch.
10. Adjust the auto stop bolt and the bow stop bolt (**Figure 43**), so the bandsaw motor will stop when the blade teeth are just below the vise table surface.
11. Go to **Setting Stops** on **Page 38** and complete the steps to make sure the cuts will be perpendicular to the table.





Figure 43. Auto stop and bow stop bolts.



Blade Guides (G0614)

The blade guides have a basic factory adjustment, but due to shipping and storage we recommend that you readjust the blade guides yourself to ensure the cuts will be your standards.



To adjust the blade guides:

1. Make sure the blade is oiled, tensioned, and tracking correctly.
2. DISCONNECT THE BANDSAW FROM POWER!
3. Raise and lock the bow in place and slide the guides together as close as you can and lock into place.
4. Remove the two Phillips head screws and the blade guide guard, (see **Figure 44**).

Tip: There should be no gap between the blade and the bearings or the carbide blade guides. To set the clearance without fighting blade twist, remove the blade guides, and set this clearance to the blade thickness and then reinstall the blade guides.

5. Make sure the guide housing has not tilted.

6. Loosen both of the cap screws (**Figure 44**) and push the guide bearing housing down until the upper carbide pad rests on the back of the saw blade.




Figure 44. Upper blade guide adjustments.

Note: To access the cap screws on the other blade guide, you must remove the two Phillips head screws (**Figure 45**), and move the limit switch and its bracket out of the way.




Figure 45. Lower blade guide limit switch.



- Loosen the cap screw, rotate the 10mm hex eccentric (**Figure 46**), and adjust the bearing against the side of the blade so there is no clearance, but the bearing is not overloaded.




Figure 46. Upper blade guide adjustments.

- Double check bearing adjustments.
- Adjust the other blade guide.
- Loosen the carbide guide cap screw and use the set screw (**Figure 44**) to set the carbide guide clearance to zero, but do not tighten the set screw so the carbide guides pinch the blade.
- Tighten the cap screw making sure that when you tighten it, the carbide guide does not rotate out of the guide housing.
- Adjust the other set of carbide guides.

- When finished with the carbide guide adjustments, make sure the ball bearing guide (**Figure 47**) adjustments have not changed. Re-adjust if required.




Figure 47. Guide types.

- Reinstall the guide guards and the limit switch and bracket.
- Adjust the auto stop bolt and the bow stop bolt (**Figure 48**), so the bandsaw motor will stop when the blade teeth are just below the vise table surface.




Figure 48. Auto stop.

- Go to **Swivel Stops** on **Page 38** and complete the steps to make sure the cuts will be perpendicular to the table.



Swivel Stops

The blade swivel stops are factory set. However, due to shipping and storage we recommend that you check the 0° degree and the 60° degree stops yourself to ensure the cuts will be your standards. **Note:** *The accuracy range for the scale is approximately 1/2° degree.*

To adjust the blade-to-vice squareness:

1. Make sure the blade is oiled, tensioned, and tracking correctly, and that the guides are set.
2. **DISCONNECT THE BANDSAW FROM POWER!**
3. Raise the bow, move and lock the headstock to zero (**Figure 49**), then lower the bow.




Figure 49. Bow and headstock moved to zero.

4. Observe the scale, and if the headstock has not completely stopped at zero, or if it has overshot the zero mark, adjust the zero stop (**Figure 50**) so it will line up with the mark .




Figure 50. Zero degree swivel stop.

5. Raise the bow, move and lock the headstock to 60° , then lower the bow.
6. Read the scale. The bandsaw blade should be at 60°.

—If the headstock did not completely reach 60°, or it has overshot the mark, adjust the stop (**Figure 51**) so it will line up with the 60° mark.




Figure 51. 60° swivel stop.

7. Go to **Blade Squaring** on **Page 40** and complete the steps to make sure the cuts will be perpendicular to the table.



Feed Stop

It may be necessary to adjust the feed stop before you make blade adjustments. The blade should never rest on or rub on any part of the vise assembly. Also, the over-tilt stop may be adjusted to stop the bow from being lifted past 40°, causing machine instability and hydraulic cylinder damage.

To adjust the feed stop bolt:

Adjust the feed stop bolt and jam nut (**Figure 52**), so the bandsaw blade teeth are just below the vise table surface when the cut is complete.




Figure 52. Feed stop bolt.

Feed Auto Stop

It may be necessary to adjust the auto stop after you have removed the limit switch for adjustment or maintenance.

To set the auto stop:

Adjust the auto stop bolt and jam nut (**Figure 53**), so the bandsaw blade teeth are just below the vise table surface when the saw blade has completed its cut.



Figure 53. Feed auto stop.



Blade-to-Vise Squareness

The blade-to-vise squareness is factory set. However, due to shipping and storage we recommend that you check the blade alignment yourself to ensure the cuts will be your standards.

To adjust the blade-to-vise squareness:

1. DISCONNECT THE BANDSAW FROM POWER!
2. Make sure the blade is oiled, tensioned, and tracking correctly, and that the guides and stops are set.
3. Raise the bow, move the headstock to zero (**Figure 54**) and lower the bow.




Figure 54. Bow and headstock moved to zero.

4. Place a quality square against the vise and the side of the blade (**Figure 55**) to verify the blade is square with the vise.




Figure 55. Checking blade squareness to vise.

—If blade is tilted and not perpendicular to the vise surface as indicated by the square, adjust the blade guide housing so it tilts the blade square with the vise.

Note: On the G0613 only one blade guide can be tilted, and on the G0614 both will need to be tilted.

5. Slide both blade guards as far as you can apart and lock into place.

Note: On the G0614, to access the cap screws on the other blade guide, remove the two Phillips head screws securing it, then move the limit switch and its bracket out of the way.

6. Loosen the two cap screws, then alternately adjust the four 4mm set screws to tilt the blade guide assembly and the blade square the vise. See **Figure 56** or **57** for your model of bandsaw.




Figure 56. G0613 blade guide adjustment.




Figure 57. G0614 blade guide adjustment.

7. Snug the 6mm cap screws in place to hold the new blade and guide setting.



Electrical Components (G0613)




Figure 58. G0613 control panel wiring.




Figure 59. G0613 main electrical box junction.




Figure 61. G0613 pump motor junction box.




Figure 60. G0613 saw motor junction box.



Figure 62. G0613 blade stop limit switch.



Electrical Components (G0614)




Figure 63. G0614 ON button.




Figure 65. G0614 OFF button.





Figure 64. G0614 Pump and speed switches.




Figure 66. G0614 Emergency stop button.



Electrical Components (G0614)




Figure 67. G0614 contactors.




Figure 68. G0614 control box.



Electrical Components (G0614)




Figure 69. G0614 pump motor data/connection.




Figure 70. G0614 pump relay.




Figure 71. G0614 saw motor connection.



Electrical Components (G0614)






Figure 72. G0614 main junction.



Figure 73. G0614 blade stop limit switch.




G0613 Wiring Diagram




G0614 Wiring Diagram

⚠ DANGER
 Disconnect power before performing any electrical service. Electricity presents serious shock hazards that will result in severe personal injury and even death!

LEGEND
 KM1: Saw Motor Contactor Low Speed
 KM2: Saw Motor Contactor High Speed
 KM3: Pump Contactor
 KM4: Saw Motor Contactor
 FR1: Overload Relay
 FU1,2,3: Fuse
 PB1: ON Button
 PB2: OFF Button
 SQ2: Emergency Stop
 SQ3: Feed Stop Limit Switch
 SB3: Pump Relay
 SB4: Speed Switch



Headstock and Bow Breakdown (G0613)




Parts List (G0613)

REF	PART #	DESCRIPTION
1	P0613001	CAP SCREW M10-1.5 X 25
2	P0613002	FLAT WASHER 10MM
3	P0613003	SHAFT
4	P0613004	ANCHOR BLOCK
5	P0613005	HEX NUT M16-2
6	P0613006	BALL BEARING 6204
7	P0613007	BODY FRAME
8	P0613008	HEX NUT M6-1
9	P0613009	HEX BOLT M6-1 X 30
10	P0613010	KNOB
11	P0613011	BLADE TENSION HANDLE
12	P0613012	CONCAVE WASHER
13	P0613013	LEADSCREW
14	P0613014	CAP SCREW M8-1.25 X 25
15	P0613015	FIXED BLOCK
16	P0613016	CAP SCREW M8-1.25 X 30
17	P0613017	LOCK WASHER 8MM
18	P0613018	REDUCER BLOCK
19	P0613019	FLAT WASHER 8MM
20	P0613020	CAP SCREW M8-1.25 X 25
21	P0613021	GEARBOX
22	P0613022	MOTOR 1HP 220V 1-PH
22-1	P0613022-1	START CAPACITOR
22-2	P0613022-2	RUN CAPACITOR
22-3	P0613022-3	FAN
22-4	P0613022-4	FAN COVER
25	P0613025	HEX BOLT M10-1.5 X 25
26	P0613026	FLAT WASHER 10MM
27	P0613027	KEY 8 X 7 X 35
28	P0613028	OUTPUT SHAFT
29	P0613029	KEY 7 X 7 X 35
30	P0613030	BALL BEARING 6206ZZ
31	P0613031	SPRING SUPPORT
32	P0613032	TENSION SPRING
33	P0613033	CAP SCREW M6-1 X 25
34	P0613034	LOCK WASHER 6MM
35	P0613035	FRAME PIVOT SHAFT
36	P0613036	CHIP COVER
37	P0613037	TAPERED BEARING 32006
38	P0613038	BLADE COVER(REAR)
39	P0613039	KNOB BOLT 3/8-24 X 1
40	P0613040	FIXED BLOCK
41	P0613041	SET SCREW M8-1.25 X 16

REF	PART #	DESCRIPTION
43	P0613043	HANDLE
44	P0613044	HANDLE PIPE
45	P0613045	BUTTON HD CAP SCR M6-1 X 25
46	P0613046	SET SCREW M8-1.25 X 8
47	P0613047	CAP SCREW M8-1.25 X 35
48	P0613048	BLADE ADJUSTMENT BAR
49	P0613049	CAP SCREW M8-1.25 X 12
50	P0613050	PHLP HD SCR M5-.8 X 10
51	P0613051	FLAT WASHER 5MM
52	P0613052	BLADE COVER (FRONT)
53	P0613053	ADJUSTMENT BLOCK (FRONT)
53-1	P0613053-1	FLOW VALVE
53-2	P0613053-2	COOLANT HOSE
53-3	P0613053-3	STEEL "T"
54	P0613054	ECCENTRIC GUIDE (L)
55	P0613055	BALL BEARING 608
57	P0613057	EXT RETAINING RING 8MM
58	P0613058	ECCENTRIC GUIDE (R)
59	P0613059	LOCK WASHER 8MM
60	P0613060	HEX NUT M8-1.25
62	P0613062	CAP SCREW M8-1.25 X 30
63	P0613063	FLAT WASHER 8MM
64	P0613064	ADJUSTMENT BLOCK (REAR)
65	P0613065	PIN
66	P0613066	BALL BEARING 608
67	P0613067	CHIP PLATE
68	P0613068	FLAT WASHER 5MM
69	P0613069	PHLP HD SCR M5-.8 X 10
70	P0613070	DRIVE WHEEL
71	P0613071	FLAT WASHER 10MM
72	P0613072	HEX BOLT M10-1.5 X 25
73	P0613073	WATERPROOF LIMIT SWITCH
73-1	P0613073-1	SWITCH BRACKET
73-2	P0613073-2	PHLP HD SCR M5-.8 X 10
73-3	P0613073-3	PHLP HD SCR M5-.8 X 35
73-4	P0613073-4	WATERPROOF POWER CORD
74	P0613074	MAIN BLADE COVER
75	P0613075	FLAT WASHER 6MM
76	P0613076	KNOB SCREW M6-1 X 10
77	P0613077	SAW BLADE
78	P0613078	IDLER WHEEL
79	P0613079	EXT RETAINING RING 25MM



Headstock and Bow Breakdown (G0614)




Parts List (G0614)

REF	PART #	DESCRIPTION
1	P0614001	CAP SCREW M10-1.5 X 25
2	P0614002	FLAT WASHER 10MM
3	P0614003	SHAFT
4	P0614004	ANCHOR BLOCK
5	P0614005	HEX NUT M16-2
6	P0614006	BALL BEARING 6205
7	P0614007	BODY FRAME
8	P0614008	HEX NUT M6-1
9	P0614009	HEX BOLT M6-1 X 30
10	P0614010	KNOB
11	P0614011	BLADE TENSION HANDLE
12	P0614012	CONCAVE WASHER
13	P0614013	LEADSCREW
14	P0614014	CAP SCREW M8-1.25 X 25L
15	P0614015	FIXED BLOCK
16	P0614016	CAP SCREW M8-1.25 X 30
17	P0614017	LOCK WASHER 8MM
18V2	P0614018V2	REDUCER BLOCK V2.06.20
19	P0614019	FLAT WASHER 8MM
20	P0614020	CAP SCREW M8-1.25 X 25
21	P0614021	GEARBOX
22	P0614022	MOTOR 220V 3-PHASE
22-1	P0614022-1	FAN
22-2	P0614022-2	COVER
25	P0614025	HEX BOLT M10-1.5 X 25
26	P0614026	FLAT WASHER 10MM
27	P0614027	KEY 8 X 7 X 35
28V2	P0614028V2	OUTPUT SHAFT V2.06.20
29	P0614029	KEY 7 X 7 X 35
30V2	P0614030V2	BALL BEARING 6208ZZ
31	P0614031	SPRING SUPPORT
32	P0614032	TENSION SPRING
33	P0614033	BRUSH
34	P0614034	CAP SCREW M6-1 X 25
35	P0614035	LOCK WASHER 6MM
36	P0614036	FRAME PIVOT SHAFT
37	P0614037	CHIP COVER
38	P0614038	TAPERED BEARING 32006
39	P0614039	LEVER BOLT 3/8-24 X 1
40	P0614040	FIXED BLOCK

REF	PART #	DESCRIPTION
41	P0614041	SET SCREW M8-1.25 X 16
43	P0614043	HANDLE
44	P0614044	HANDLE PIPE
45	P0614045	BUTTON HD CAP SCR M6-1 X 20
46	P0614046	SET SCREW M8-1.25 X 8
47	P0614047	CAP SCREW M8-1.25 X 35
48	P0614048	BLADE ADJUSTMENT BAR
49	P0614049	CAP SCREW M8-1.25 X 12
50	P0614050	PHLP HD SCR M5-.8 X 10
51	P0614051	FLAT WASHER 5MM
52	P0614052	BLADE COVER (FRONT)
53	P0614053	ADJUSTMENT BLOCK (FRONT)
53-1	P0614053-1	FLOW VALVE
53-2	P0614053-2	COOLANT HOSE
53-3	P0614053-3	STEEL "T"
54	P0614054	GUIDE
55	P0614055	GUIDE
56	P0614056	BUTTON HD CAP SCR M6-1 X 20
57	P0614057	ECCENTRIC GUIDE
58	P0614058	BALL BEARING 608
59	P0614059	PHLP HD SCR M5-.8 X 25
60	P0614060	ECCENTRIC GUIDE
62	P0614062	CAP SCR M5-.8 X 15
63	P0614063	CAP SCREW M8-1.25 X 35
64	P0614064	LOCK WASHER 8MM
65	P0614065	ADJUSTMENT BLOCK (REAR)
66	P0614066	CAP SCREW M8-1.25 X 12
67	P0614067	CHIP PLATE
68	P0614068	BLADE COVER (REAR)
69	P0614069	FLAT WASHER 5MM
70	P0614070	PHLP HD SCR M5-.8 X 10
71	P0614071	DRIVE WHEEL
72	P0614072	FLAT WASHER 10MM
73	P0614073	HEX BOLT M10-1.5 X 25
75	P0614075	MAIN BLADE COVER
76	P0614076	FLAT WASHER 6MM
77	P0614077	KNOB SCREW M6-1 X 10
78	P0614078	SAW BLADE
79	P0614079	IDLER WHEEL
80	P0614080	EXT RETAINING RING 25MM



Base Breakdown (G0613)




Parts List (G0613)

REF	PART #	DESCRIPTION
100	P0613100	WISE JAW ADJUSTABLE ROD
101	P0613101	RETAINER
102	P0613102	SWIVEL ARM
102-1	P0613102-1	HEX BOLT M10-1.5 X 35
103	P0613103	HEX NUT M10-1.5
104	P0613104	HEX BOLT M10-1.5 X 30
105	P0613105	DISTANCE SET ROD
106	P0613106	KNOB NUT M6-1
107	P0613107	BRACKET
108	P0613108	PHLP HD SCR M6-1 X 20
109	P0613109	BALL BEARING 32006
110	P0613110	BUSHING
111	P0613111	BEARING COVER
112	P0613112	SPANNER NUT M30 X 1.5
113	P0613113	CAP SCREW M6-1 X 16
114	P0613114	LOCK WASHER 6MM
115	P0613115	SPRING ANCHOR
116	P0613116	L-BRACKET
117	P0613117	LOCK WASHER 8MM
118	P0613118	CAP SCREW M8-1.25 X 25
119	P0613119	PHLP HD SCR M5-.8 X 8
120	P0613120	SCREEN
121	P0613121	BASE
121-1	P0613121-1	BASE CABINET
122	P0613122	COVER
123	P0613123	SWIVEL PLATE
124	P0613124	HEX NUT M10-1.5
125	P0613125	HEX BOLT M10-1.5 X 30
126	P0613126	FIXED PLATE
127	P0613127	BUTTON HD CAP SCR M6-1 X 16
128	P0613128	CAP SCREW M10-1.5 X 35
129	P0613129	NUT
130	P0613130	ADJUSTABLE HANDLE

REF	PART #	DESCRIPTION
131	P0613131	HEX NUT M10-1.5
132	P0613132	HEX BOLT M10-1.5 X 30
133	P0613133	HEX PLUG 3/8PT
134	P0613134	CAP SCR M6-1 X 16
135	P0613135	LOCK WASHER 6MM
136	P0613136	PUMP 110V, SINGLE PHASE
136-1	P0613136-1	COOLANT HOSE
139	P0613139	CYLINDER BRACKET
143	P0613143	CYLINDER
144	P0613144	CAP SCREW M12-1.75 X 80
145	P0613145	CAP SCREW M10-1.5 X 55
180	P0613180	BUTTON HD CAP SCR M8-1.25 X 20
181	P0613181	FLAT WASHER 8MM
182	P0613182	HANDWHEEL
183	P0613183	ROLL PIN
184	P0613184	BEARING COVER
185	P0613185	BALL BEARING 51106
186	P0613186	WISE BED
187	P0613187	TENSION SPRING
188	P0613188	BUSHING
189	P0613189	PHLP HD SCR M6-1 X 16
190	P0613190	WISE JAW BRACKET(FRONT)
191	P0613191	WISE PLATE
192	P0613192	FLAT HD SCR M8-1.25 X 16
193	P0613193	SET SCREW M8-1.25 X 20
194	P0613194	HEX NUT M8-1.25
195	P0613195	O-RING
196	P0613196	FLAT WASHER 8MM
197	P0613197	CAP SCREW M8-1.25 X 20
198	P0613198	LEADSCREW A
198-1	P0613198-1	LEADSCREW LOCK LEVER
199	P0613199	WISE JAW BRACKET(REAR)
199-1	P0613199-1	GIB



Base Breakdown (G0614)




Parts List (G0614)

REF	PART #	DESCRIPTION
100	P0614100	WISE JAW BRACKET(REAR)
101	P0614101	WISE JAW ADJUSTABLE ROD
102	P0614102	RETAINER
103	P0614103	SWIVEL ARM
103-1	P0614103-1	HEX BOLT M10-1.5 X 35
104	P0614104	HEX NUT M10-1.5
105	P0614105	HEX BOLT M10-1.5 X 30
106	P0614106	DISTANCE SET ROD
107	P0614107	BRACKET
108	P0614108	LEVER
109	P0614109	PHLP HD SCR M6-1 X 20
110	P0614110	BALL BEARING 32006
111	P0614111	BUSHING
112	P0614112	BEARING COVER
113	P0614113	SPANNER NUT M30 X 1.5
114	P0614114	CAP SCREW M6-1 X 16
115	P0614115	LOCK WASHER 6MM
116	P0614116	SPRING ANCHOR
117	P0614117	L-BRACKET
118	P0614118	LOCK WASHER 8MM
119	P0614119	CAP SCREW M8-1.25 X 25
120	P0614120	PHLP HD SCR M5-.8 X 8
121	P0614121	SCREEN
122	P0614122	BASE
122-1	P0614122-1	BASE CABINET
123	P0614123	COVER
123-1	P0614123-1	PHLP HD SCR M6-1 X 12
124	P0614124	SWIVEL PLATE
126	P0614126	HEX BOLT M10-1.5 X 30
127	P0614127	HEX NUT M10-1.5
128	P0614128	FIXED PLATE
129	P0614129	BUTTON HD CAP SCR M6-1 X 16
130	P0614130	CAP SCREW M10-1.5 X 35

REF	PART #	DESCRIPTION
131	P0614131	NUT
132	P0614132	ADJUSTABLE HANDLE
133	P0614133	HEX PLUG 3/8PT
134	P0614134	CAP SCR M6-1 X 16
135	P0614135	FLAT WASHER 6MM
136	P0614136	PUMP 220V, 3-PHASE
136-1	P0614136-1	PLASTIC TUBING
140	P0614140	CYLINDER
141	P0614141	WATERPROOF LIMIT SWITCH
141-1	P0614141-1	WATERPROOF POWER CORD
142	P0614142	SWITCH PLADE
143	P0614143	PHLP HD SCR M5-.8 X 35
144	P0614144	CAP SCREW M12-1.75 X 80
145	P0614145	CAP SCREW M10-1.5 X 55
181	P0614181	BUTTON HD CAP SCR M8-1.25 X 20
182	P0614182	FLAT WASHER 8MM
183	P0614183	WHEEL
184	P0614184	ROLL PIN
185	P0614185	BEARING COVER
186	P0614186	BALL BEARING 51106
187	P0614187	WISE HANDLE
188	P0614188	TENSION SPRING
189	P0614189	BUSHING
190	P0614190	CAP SCREW M6-1 X 25
191	P0614191	WISE JAW BRACKET(FRONT)
192	P0614192	WISE PLATE
193	P0614193	FLAT HD SCR M8-1.25 X 16
194	P0614194	SET SCREW M8-1.25 X 20
195	P0614195	HEX NUT M8-1.25
196	P0614196	GIB
197	P0614197	FLAT WASHER 8MM
198	P0614198	CAP SCREW M8-1.25 X 20
199	P0614199	LEADSCREW A



Electrical Box Breakdown (G0613)




Parts List (G0613)

REF	PART #	DESCRIPTION
233	P0613233	CAP SCREW M6-1 X 35
234	P0613234	FLAT WASHER 8MM
235	P0613235	CONTROL BOX
237	P0613237	CONTROL BOX COVER
238	P0613238	CONTROL BOX STAND
242	P0613242	HANDLE
243	P0613243	CAP SCREW M8-1.25 X 20
244	P0613244	PHLP HD SCR M6-1 X 12
255	P0613255	PUMP ROTARY SWITCH V1

REF	PART #	DESCRIPTION
257	P0613257	ON/OFF & EMGNCY SW 110V
257A	P0613257A	ON/OFF & EMGNCY SW 220V
258	P0613258	MOTOR POWER CORD 110V
259	P0613259	PUMP POWER CORD 110V
260	P0613260	POWER SUPPLY CORD 110V
262	P0613262	JUNCTION BLOCK
263	P0613263	CIRCUIT BREAKER 15A 110V
263A	P0613263A	CIRCUIT BREAKER 7A 220V
264	P0613264	220V CONVERSION KIT



Electrical Box Breakdown (G0614)




Parts List (G0614)

REF	PART #	DESCRIPTION
232	P0614232	LOCK WASHER 6MM
233	P0614233	CAP SCREW M6-1 X 35
234	P0614234	FLAT WASHER 8MM
235	P0614235	CONTROL BOX
236	P0614236	ELECTRICAL MOUNTING PLATE
237	P0614237	CONTROL BOX COVER
238	P0614238	CONTROL BOX STAND
242	P0614242	HANDLE
243	P0614243	CAP SCREW M8-1.25 X 20
244	P0614244	PHLP HD SCR M6-1 X 12
245	P0614245	GROUND PLATE
246	P0614246	FUSE HOUSING V1
247	P0614247	FUSE V1
248	P0614248	RELAY RXL 4A06B1P7 PYF14A

REF	PART #	DESCRIPTION
249	P0614249	RELAY BASE MY 4-14A
250	P0614250	CONTACTOR 220V TCF-4 V1
251	P0614251	CONTACTOR 220V TC-11 V1
250-1	P0614250-1	CONTACTOR 220V TCF-4
252	P0614252	CONTACTOR 220V TC-11 V1
252-1	P0614252-1	OL RELAY 220V THR-12 V1
253	P0614253	ON PUSH BUTTON V1
254	P0614254	MOTOR 2-SPEED SWITCH V1
255	P0614255	PUMP ROTARY SWITCH V1
256	P0614256	OFF PUSH BUTTON SWITCH V1
257	P0614257	EMERGENCY STOP SWITCH
258	P0614258	MOTOR POWER CORD 3-PHASE
259	P0614259	PUMP POWER CORD 3-PHASE
260	P0614260	POWER SUPPLY CORD 3-PHASE



Cabinet & Gearbox (G0613 & G0614)



Parts List (G0613)

REF	PART #	DESCRIPTION
300	P0613300	FRONT PANEL
301	P0613301	REAR PANEL
302	P0613302	SIDE PANEL
303	P0613303	HEX NUT 5/16-18
304	P0613304	FLAT WASHER 8MM
305	P0613305	CARRIAGE BOLT 5/16-18 X 5/8
306	P0613306	FLAT WASHER 10MM
307	P0613307	HEX BOLT M10-1.5 X 25
308	P0613308	MOTOR FLANGE
309	P0613309	O-RING
310	P0613310	BALL BEARING 6006ZZ
311	P0613311	WORM SHAFT
312	P0613312	O-RING
313	P0613313	OUTPUT SHAFT COVER
314	P0613314	OIL SEAL

REF	PART #	DESCRIPTION
315	P0613315	CAP SCREW M6-1 X 20
316	P0613316	BALL BEARING 6008
317	P0613317	WORM WHEEL
318	P0613318	OUTPUT SHAFT
319	P0613319	BALL BEARING 6008
320	P0613320	OIL SEAL
321	P0613321	HEX BOLT M6-1 X 25
322	P0613322	HOUSING
323	P0613323	OIL SEAL
324	P0613324	BALL BEARING 6204ZZ
325	P0613325	EXT RETAINING RING 47MM
326	P0613326	OIL SEAL
326-1	P0613326-1	OIL SEAL COVER
326-2	P0613326-2	HEX BOLT 1/4-20 X 3/8


Parts List (G0614)

REF	PART #	DESCRIPTION
300	P0614300	FRONT PANEL
301	P0614301	REAR PANEL
302	P0614302	SIDE PANEL
303	P0614303	HEX NUT 5/16-18
305	P0614305	CARRIAGE BOLT 5/16-18 X 5/8
306	P0614306	FLAT WASHER 10MM
307	P0614307	HEX BOLT M10-1.5 X 25
308	P0614308	MOTOR FLANGE
309	P0614309	O-RING
310	P0614310	BALL BEARING 6006ZZ
311	P0614311	WORM SHAFT
312	P0614312	O-RING
313	P0614313	OUTPUT SHAFT COVER
314	P0614314	OIL SEAL

REF	PART #	DESCRIPTION
315	P0614315	CAP SCREW M6-1 X 20
316	P0614316	BALL BEARING 6008
317	P0614317	WORM WHEEL
318	P0614318	OUTPUT SHAFT
319	P0614319	BALL BEARING 6008
320	P0614320	OIL SEAL
321	P0614321	HEX BOLT M6-1 X 25
322	P0614322	HOUSING
323	P0614323	OIL SEAL
324	P0614324	BALL BEARING 6204ZZ
325	P0614325	EXT RETAINING RING 47MM
326	P0614326	OIL SEAL
326-1	P0614326-1	OIL SEAL COVER
326-2	P0614326-2	HEX BOLT 1/4-20 X 3/8



Labels and Placement



REF	PART #	DESCRIPTION
401	P0613401	FINGERS CUT WARNING LABEL
402	P0613402	WEAR SAFETY GLASSES LABEL
403	P0613403	ENTANGLEMENT LABEL
404	P0613404	GRIZZLY LOGO PLATE
405	P0613405	ELECTRICITY LABEL
406	P0613406	READ MANUAL LABEL
407	P0613407	UNPLUG 220V LABEL

REF	PART #	DESCRIPTION
408	P0613408	HEARING PROTECTION LABEL
409	P0613409	LOCK AND UNLOCK LABEL
410	P0613410	G0613 DATA LABEL
411	P0613411	BLADE DIRECTION LABEL
412	P0613412	MODEL NUMBER LABEL (G0613)
413	P0614413	MODEL NUMBER LABEL (G0614)

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.





WARRANTY CARD

Name _____
 Street _____
 City _____ State _____ Zip _____
 Phone # _____ Email _____
 Model # _____ Order # _____ Serial # _____

The following information is given on a voluntary basis. It will be used for marketing purposes to help us develop better products and services. **Of course, all information is strictly confidential.**

- How did you learn about us?

<input type="checkbox"/> Advertisement	<input type="checkbox"/> Friend	<input type="checkbox"/> Catalog
<input type="checkbox"/> Card Deck	<input type="checkbox"/> Website	<input type="checkbox"/> Other:
- Which of the following magazines do you subscribe to?

<input type="checkbox"/> Cabinetmaker & FDM	<input type="checkbox"/> Popular Science	<input type="checkbox"/> Wooden Boat
<input type="checkbox"/> Family Handyman	<input type="checkbox"/> Popular Woodworking	<input type="checkbox"/> Woodshop News
<input type="checkbox"/> Hand Loader	<input type="checkbox"/> Precision Shooter	<input type="checkbox"/> Woodsmith
<input type="checkbox"/> Handy	<input type="checkbox"/> Projects in Metal	<input type="checkbox"/> Woodwork
<input type="checkbox"/> Home Shop Machinist	<input type="checkbox"/> RC Modeler	<input type="checkbox"/> Woodworker West
<input type="checkbox"/> Journal of Light Cont.	<input type="checkbox"/> Rifle	<input type="checkbox"/> Woodworker's Journal
<input type="checkbox"/> Live Steam	<input type="checkbox"/> Shop Notes	<input type="checkbox"/> Other:
<input type="checkbox"/> Model Airplane News	<input type="checkbox"/> Shotgun News	
<input type="checkbox"/> Old House Journal	<input type="checkbox"/> Today's Homeowner	
<input type="checkbox"/> Popular Mechanics	<input type="checkbox"/> Wood	
- What is your annual household income?

<input type="checkbox"/> \$20,000-\$29,000	<input type="checkbox"/> \$30,000-\$39,000	<input type="checkbox"/> \$40,000-\$49,000
<input type="checkbox"/> \$50,000-\$59,000	<input type="checkbox"/> \$60,000-\$69,000	<input type="checkbox"/> \$70,000+
- What is your age group?

<input type="checkbox"/> 20-29	<input type="checkbox"/> 30-39	<input type="checkbox"/> 40-49
<input type="checkbox"/> 50-59	<input type="checkbox"/> 60-69	<input type="checkbox"/> 70+
- How long have you been a woodworker/metalworker?

<input type="checkbox"/> 0-2 Years	<input type="checkbox"/> 2-8 Years	<input type="checkbox"/> 8-20 Years	<input type="checkbox"/> 20+ Years
------------------------------------	------------------------------------	-------------------------------------	------------------------------------
- How many of your machines or tools are Grizzly?

<input type="checkbox"/> 0-2	<input type="checkbox"/> 3-5	<input type="checkbox"/> 6-9	<input type="checkbox"/> 10+
------------------------------	------------------------------	------------------------------	------------------------------
- Do you think your machine represents a good value? Yes No
- Would you recommend Grizzly Industrial to a friend? Yes No
- Would you allow us to use your name as a reference for Grizzly customers in your area?
Note: We never use names more than 3 times. Yes No

10. Comments: _____

CUT ALONG DOTTED LINE

FOLD ALONG DOTTED LINE



Place
Stamp
Here



GRIZZLY INDUSTRIAL, INC.
P.O. BOX 2069
BELLINGHAM, WA 98227-2069



FOLD ALONG DOTTED LINE

Send a Grizzly Catalog to a friend:

Name _____
Street _____
City _____ State _____ Zip _____

TAPE ALONG EDGES--PLEASE DO NOT STAPLE

WARRANTY AND RETURNS

Grizzly Industrial, Inc. warrants every product it sells for a period of **1 year** to the original purchaser from the date of purchase. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence, accidents, repairs or alterations or lack of maintenance. This is Grizzly's sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant or represent that the merchandise complies with the provisions of any law or acts unless the manufacturer so warrants. In no event shall Grizzly's liability under this warranty exceed the purchase price paid for the product and any legal actions brought against Grizzly shall be tried in the State of Washington, County of Whatcom.

We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special, or consequential damages arising from the use of our products.

To take advantage of this warranty, contact us by mail or phone and give us all the details. We will then issue you a "Return Number," which must be clearly posted on the outside as well as the inside of the carton. We will not accept any item back without this number. Proof of purchase must accompany the merchandise.

The manufacturers reserve the right to change specifications at any time because they constantly strive to achieve better quality equipment. We make every effort to ensure that our products meet high quality and durability standards and we hope you never need to use this warranty.

Please feel free to write or call us if you have any questions about the machine or the manual.

Thank you again for your business and continued support. We hope to serve you again soon.

grizzly.com[®]

TOOL WEBSITE

Buy Direct and Save with Grizzly[®] – Trusted, Proven and a Great Value!
~Since 1983~

*Visit Our Website Today For
Current Specials!*

**ORDER
24 HOURS A DAY!
1-800-523-4777**

