


Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	P0496001	FRAME
1-1	P0496001-1	CLAMP
1-2	P0496001-2	SUPPORT BRACKET
2	P0496002	SPACER
3	P0496003	UPPER WHEEL KNOB 1/2-12
4	P0496004	SPECIAL WASHER 1/2
5	P0496005	UPPER WHEEL SHAFT
6	P0496006	WHEEL SHAFT
7	P0496007	UPPER AXLE LATCH
8	P0496008	UPPER WHEEL BRACKET
9	P0496009	INNER TUBE
9-1	P0496009-1	SPECIAL SCREW
9-2	P0496009-2	COLLAR
10	P0496010	OUTER TUBE
11	P0496011	T-BUSHING
12	P0496012	JACK SCREW
13	P0496013	QUICK RELEASE LEVER
13-1	P0496013-1	CAM
13-2	P0496013-2	SPACER
14	P0496014	UPPER WHEEL RESTING SHAFT
15	P0496015	LOWER WHEEL RESTING SHAFT
16	P0496016	LOWER WHEEL STORAGE BRACKET
17	P0496017	UPPER WHEEL STORAGE BRACKET
18	P0496018	LOWER WHEEL A
19	P0496019	LOWER WHEEL B
20	P0496020	LOWER WHEEL C

REF	PART #	DESCRIPTION
21	P0496021	LOWER WHEEL D
22	P0496022	LOWER WHEEL E
23	P0496023	LOWER WHEEL F
24	P0496024	NARROW GROOVE WHEEL
25	P0496025	WIDE GROOVE WHEEL
26	P0496026	STEP ROLLER WHEEL
27	P0496027	NARROW RIDGE UPPER WHEEL
28	P0496028	WIDE RIDGE UPPER WHEEL
29	P0496029	FLAT UPPER WHEEL
30	P0496030	LOWER WHEEL BRACKET
31	P6204	BALL BEARING 6204ZZ
32	P0496032	KICK WHEEL
33	PLW02	LOCK WASHER 1/4
34	PSB05	CAP SCREW 1/4-20 X 3/4
35	PSB06	CAP SCREW 1/4-20 X 1
36	PW06	FLAT WASHER 1/4
37	PSS07	SET SCREW 1/4-20 X 1/2
38	PSBS20	BUTTON HD CAP SCR 1/4-20 X 1/2
39	PAW05M	HEX WRENCH 5MM
40	PSB19	CAP SCREW 3/8-16 X 1-1/4
41	PR09M	EXT RETAINING RING 20MM
42	PSS04	SET SCREW 1/4-20 X 5/16
43	P0496043	G0496 MACHINE ID LABEL
44	P0496044	PINCH HAZARD LABEL 1-1/2" X 2-1/2"
45	PLABEL-12	READ MANUAL LABEL

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

