


Parts Breakdown H3256



REF	PART #	DESCRIPTION
1	PH3256001	FLUID ADJUSTMENT SCREW
2	PH3256002	FLUID ADJUSTMENT KNOB
3	PH3256003	O-RING
4	PH3256004	WASHER
5	PH3256005	AIR VALVE SPRING
6	PH3256006	AIR INLET VALVE
7	PH3256007	SWITCH SPRING
8	PH3256008	AIR INLET VALVE ASSEMBLY
9	PH3256009	SWITCH KNOB
10	PH3256010	SWITCH WASHER
11	PH3256011	LOCK SCREW
12	PH3256012	NUT
13	PH3256013	AIR CAP WASHER
14	PH3256014	ATOMIZATION CAP
15	PH3256015	NUT HOUSING
16	PH3256016	FLUID NOZZLE
17	PH3256017	FLUID NOZZLE WASHER
18	PH3256018	BOLT
19	PH3256019	COMPRESSION SPRING
20	PH3256020	NEEDLE WASHER
21	PH3256021	TRIGGER LEVER I
22	PH3256022	TRIGGER LEVER II

REF	PART #	DESCRIPTION
23	PH3256023	TRIGGER
24	PH3256024	SNAP RETAINER
25	PH3256025	SNAP RETAINER
26	PH3256026	CUP LID
27	PH3256027	CUP
28	PH3256028	FILTER
29	PH3256029	FLUID INLET JOINT
30	PH3256030	FLUID NEEDLE
31	PH3256031	FLUID NEEDLE SPRING
32	PH3256032	JOINT
33	PH3256033	PAINT ADJUSTMENT KNOB
34	PH3256034	PHILLIPS SCREW
35	PH3256035	PATTERN ADJUSTMENT KNOB
36	PH3256036	PATTERN ADJUSTMENT SCREW
37	PH3256037	O-RING
38	PH3256038	O-RING
39	PH3256039	SNAP RETAINER
40	PH3256040	FIXED NUT
41	PH3256041	O-RING
42	PH3256042	AIR INLET JOINT
43*	PH3256043	CLEANING BRUSH
44*	PH3256044	BARBED AIR FITTING 1/4" NPT

* Not shown in parts breakdown